

Hunter-Pro 832/896/8144 Captain 8

S e c u r i t y S y s t e m s



User Guide

PIMA
FOR BETTER PROTECTION



Quick Reference

Key	Press ^{PROG} 0 for 2 seconds, enter User code and press the key to...	Press the key for 2 seconds* to...
ON/OFF 1	Arm to full mode, disarm	Quickly arm to full mode*
MEMO. 2	Display the log	-
BYPASS 3	Temporarily bypass zones	-
HOME 1 4	Arm to "Home 1" mode	Quickly arm to "Home 1" mode*
ZONE 5	Display modes menu	Display the "All Zones" mode for a minute
PHONES 6	Set the telephone numbers	-
HOME 2 7	Arm to "Home 2" mode	Quickly arm to "Home 2" mode*
CLOCK 8	Set time and date	-
CODES 9	Set the user codes	-
CHIME *	Set the chime per zone	Turn ON/Off the chime feature in chime zones
PROG. 0	Set auto-arming by day and inactivity	-
RESET #	-	Reset smoke detectors. Press briefly: display armed partitions
END	-	Silence the keypad buzzer when it beeps
SERVICE NEXT	Display the system's name & version	Display the service provider
TEST BACK	Initiate system tests	-
ENTR	-	Display the system's name & version
CHIME * + RESET #	Press for 2 seconds: create Panic alarm	
ENTR + END	Press briefly: turn ON/OFF the keypad chime	

Factory default codes

Master: 5555
Technician: 1234

* Commands marked with an asterisk must be enabled by the Installer.

Table of Contents

1	INTRODUCTION.....	5
1.1	Hunter-Pro & Captain 8 mutual features.....	5
1.2	Hunter-Pro Series unique features.....	5
1.3	Captain 8 unique features	6
1.4	Safety & Security	6
1.5	Signs and conventions in this guide.....	6
1.6	System codes	7
1.6.1	The Master code.....	7
1.6.2	User codes	7
1.7	The User Menu	7
1.8	The LCD Keypad	7
2	ARMING & DISARMING THE SYSTEM (KEY #1).....	8
2.1	Arming	8
2.1.1	Via the keypad.....	9
2.1.2	Fast arming	9
2.2	Disarming	9
2.2.1	With the DURESS code.....	9
3	THE SYSTEM LOG (KEY #2)	10
3.1	Log list sorting options.....	10
4	TEMPORARILY BYPASSING OPEN ZONES (KEY #3)	11
4.1	When arming.....	11
4.2	Prior to arming	11
5	"HOME 1" & "HOME 2" ARMING MODES (KEYS 4, 7)	12
6	DISPLAYING TYPES (KEY #5).....	13
6.1	Fast 32-zone display.....	13
6.2	Scan open zones.....	14
6.3	Disable zone displaying.....	15
6.4	Other displaying types	15
6.4.1	All Zones.....	15
6.4.2	Bypassed Zones	15
6.4.3	Soaked Zones.....	16
6.4.4	Chime Zones	16
6.4.5	All Zones Status.....	16
6.5	Show partition names.....	17
7	PHONE NUMBERS, SMS SETTINGS & DIALER TEST (KEY 6).....	17
7.1	Phone numbers.....	17
7.2	SMS messages.....	18
7.2.1	A demo SMS message.....	18
7.3	Dialer test.....	18
8	SETTING TIME AND DATE (KEY 8)	19
9	CODES (KEY 9)	19
9.1	The Master Code	19
9.1.1	Changing the code.....	19
9.2	User codes	20
9.2.1	Adding or change a code	20
9.2.2	Deleting a code	20
9.3	User name	20
9.4	User settings	21
9.5	Disarming Time Frame.....	22
9.6	User's partitions.....	22
9.7	Adding a key fob	23
9.8	Deleting a key fob.....	23

9.9	Adding RFID tag/keychain	23
9.10	Deleting RFID Tag	24
9.11	The DURESS code	24
9.12	The Short code	24
9.13	The Door code	24
10	AUTOMATIC ARMING (KEY 9)	25
10.1	By day and hour	25
10.1.1	Inactivity auto-arming	25
11	THE CHIME FEATURE (KEY #)	26
11.1	Enabling and disabling the Chime globally	26
12	OTHER TOPICS	26
12.1	Partitions	26
12.1.1	Examples	27
12.1.2	Displaying armed partitions	29
12.2	Arming with key, key fob or RFID tag/key chain	29
12.2.1	Arming with a key fob	29
12.3	Enabling Remote Upload	30
12.4	Names and Characters	30
12.4.1	Example	31
12.5	PANIC alarm	31
12.6	Resetting Smoke/Fire/Anti-mask detectors	32
12.7	Turning the keypad chime ON/OFF	32
12.8	Comparison between the Hunter-Pro Series models	32
12.9	Comparison between the Hunter-Pro 896 & Captain 8	32
13	MANUAL SYSTEM TESTS (BACK KEY)	33
14	REMOTE CONTROL VIA THE PHONE	33
14.1	Basic mode	34
14.2	Full mode	34
14.2.1	Examples	35
15	TROUBLESHOOTING	36
16	APPENDIX: ZONE LOCATION TABLE	38

1 INTRODUCTION

Congratulations on your purchase of the HUNTER-PRO Series and Captain 8 intruder alarm systems. Much care has been taken in developing these systems, to provide you with unprecedented peace of mind and security. The user-friendly menu with its advanced features will professionally help you to protect your premises.

We recommend reading this guide in its entirety in order to familiarize you with the system and take full advantage of its features.

To assure optimal safety and security, you should perform a system test once a week. See section 13 for details.

For any further questions, please contact your local PIMA distributor.

1.1 Hunter-Pro & Captain 8 mutual features

- Hybrid systems with hardwired and wireless zones;
- Operating modes: full or partial, "HOME 1" & "HOME 2";
- Equipped with menu-driven LCD and Graphic keypads, and cost-effective LED keypads;
- Optional use of partitions for perimeter zones and separate locations;
- Various automatic arming;
- Various codes & access options including RFID tag/keychain and key fob;
- Authorization settings per user;
- Up to four phone numbers to call the Monitoring Station and four to the owner;
- Optional disarming time frame per user;
- Constant zone, battery and phone line testing;
- Communication channels: phone, Long-range Radio, GSM, GPRS, Ethernet;
- Various ways to arm and disarm the system: keypad, key switch, RFID tag/keychain, auto-arming;
- Full wireless detectors supervision;
- Optional alarm voice messages and listen in microphone;
- Various methods for preventing false alarms;
- Full log, part is non-volatile.

1.2 Hunter-Pro Series unique features

- 8 to 32/96/144 zones;
- Up to 32/96/144 user codes and RFID tags;
- Phone remote control;
- Various partitioning options:
 - Up to 16 partitions;
 - Up to 8 subsystems.



1.3 Captain 8 unique features

- 8-16 zones;
- Up to 30 user codes & RFID tags;
- Various partitioning options:
 - Up to 4 partitions;
 - Up to 4 subsystems.



1.4 Safety & Security



Both the HUNTER-PRO Series & the Captain 8 systems have been registered in accordance with the EN60950 standard.

We advise you the following:

- The alarm system as well as its wiring should be placed in a hidden and safe location, protected from rain or moisture.
- The alarm system may have hazards of electric shock and fire. Do not try to open the alarm system's case: dangerous high voltages are present inside it. Refer servicing to qualified personnel only.
- This alarm system should be used with 230VAC 50Hz, protected by anti-electric shock breaker. To prevent electric shocks and fire hazards, do NOT use any other power source.

1.5 Signs and conventions in this guide



Press a key briefly



Press a key for 2 seconds, until confirmation beep sounds



Warning



Note

NEXT

In programming mode, moves the cursor to the right.

BACK

In programming mode, moves the cursor to the left.

ENTR

Enter, Save

#

In programming mode, enables ('+') or disables ('-') a parameter; erase character.

END

Press briefly: Cancel; Return.

Press for 2 seconds: Silence the keypad chime in faults.

The numbers that are printed above and below the keypad's screen stand for zone numbers and partition numbers.

1.6 System codes

1.6.1 The Master code

- The Master code is a super user code, with all the access authorizations.
- It is mainly used for changing the “Master Code” itself.

1.6.2 User codes

- In the Hunter-Pro Series and Captain 8 alarm systems, the User code is the user ID, i.e., every user detail and authorization are set under that code.
- User codes are assigned separately per user.
- A User code can be restricted to only parts of the user menu, i.e., can only set these menus.

1.7 The User Menu

- The User menu is where parameters such as Time & Date, User codes and User authorizations are set.
- It is accessed by pressing  for 2 seconds and entering a User code. See section 9.4 for restrictions.
- By default, entering a User code arms or disarms the alarm system (toggle mode). The Installer can program the system, so entering the code displays the User menu.
- After entering the User menu, the sub-menus are accessed directly, by pressing the keypad keys. Each key menu is printed above it, e.g. “Time”, “Codes”.

1.8 The LCD Keypad

- RXN-400, RXN-410 and RXN-410 RFID are PIMA's LCD keypads. They are designed for maximum simplicity and durability and present decorative design. The RXN-400 & RXN-410 are identical, except for their screen size: 410's is larger.
- The screen is made of 2 lines with 16 characters in each. The upper line displays the time and the date (depending on the display type). Both lines display data regarding the system, such as events, faults and zone status.



- Up to 8 supervised keypads can be connected to the system simultaneously.
- The message “Other Keypad in Use” is displayed when another keypad is in use, or when the system is remotely controlled.



Figure 1. RXN-410 with the "Fast" display type

2 ARMING & DISARMING THE SYSTEM (KEY #1)

- The system can be armed in one of 4 ways:
 1. Via the keypad;
 2. Automatically;
 3. Using Key fob, key switch and RFID tag/keychain;
 4. In Hunter-Pro only: by a remote control and via the phone.
- As a rule, arming should be carried out only when all the zones are closed, but those on the exit route, and there are no alarms (e.g., fire, panic) or faults (e.g., low battery):
 - In the "Fast zone" display type, no zone is indicated with a rectangle ■■■;
 - In the "Scan open zones" display type, no zone is indicated with "OP" (open).
- Zones like exit doors and areas near the keypad are delayed on the exit and the entry, so whoever arms (or disarms) the system will have enough time to walk from the keypad to the door, (or the other way, when entering) without triggering any detector.
- The Exit & Entry delay times are separate and programmed by the Installer. The Installer can also program two different Entry delays to different zones.


2.1 Arming

- To arm your system, enter a user code (see section 9.4 for restrictions) or the Short code (a code programmed by the Installer. See section 9.12).
- If no zone is open and there are no faults, the Exit delay countdown starts, the keypad buzzer sounds beeps and the green ARMED LED flashes. You can now exit the premises and close the door behind you¹.

¹ The Exit delay countdown can start immediately as soon as the final door is closed. Refer to the Installer.


- When the Exit delay ends, the system becomes armed: the green ARMED LED stops to flash and stays on, the beeps stop, the message "System Armed" is briefly displayed and then the date and time are displayed.

2.1.1 Via the keypad



- The Exit delay time span is set by the Installer.

2.1.2 Fast arming




- Fast/single keystroke arming must be enabled by the Installer.
- To set the Short code, see section 9.12.

2.2 Disarming



- To disarm the system, enter a user code.
- If an "Access denied" message is displayed, the user may be trying to disarm it outside her/his "Disarming time frame". See section 9.5

2.2.1 With the DURESS code



- The DURESS code is a code to be used in threat situations, where you are being forced to disarm the system. Hence, the code can be used only for disarming.
- Entering the DURESS code disarms the system, and in the same time sends a silent alarm to the Monitoring Station (if you are subscriber) and your phones.
- To set the code, refer to section 9.3.


3 THE SYSTEM LOG (KEY #2)



- The system logs alarms, arming & disarming, zone bypassing, faults, code changing and other actions, chronologically.
- Any action taken by a user is logged with the User name.
- Part of the log is non-volatile (see the table on page 32).

3.1 Log list sorting options

- A log entry contains, on the upper line, a serial number and the date & time stamp when the entry (i.e., the event) was logged; the event details appear on the bottom line.
- The log has 4 list sorting options: "All the events", which displays all the log entries in one list, "Faults only", "Zone alarms" and "Arming/disarming".
- When you view one of these lists, pressing a number between 0-3, transforms to corresponding list: 0-"All the events", 1-"Faults only", 2-"Zone alarms", 3-"Arming/disarming".
- Entry example: "Burglary" alarm in zone #4, called "Kitchen"; the two screens are displayed intermittently.




4 TEMPORARILY BYPASSING OPEN ZONES (KEY #3)



- **Bypassing zones reduces the safety of your protected premises!**
- **It should be used carefully, only if there is no alternative and only for the shortest possible time.**
- **If you bypass a zone due to a fault, a service technician should be called;**
- **Beware not to bypass zones unintentionally;**
- **Zones can be bypassed only when the system is disarmed;**

- A bypassed zone does not sound the alarm when violated, nor does it report the Monitoring Center.
- Temporarily bypassed zones are automatically reinstated when the system is disarmed;
- The letter "B" in "Fast zone display" mode indicates a bypassed zone.
- A service technician can permanently bypass a zone, such in the case of a zone that no longer needs to be protected

4.1 When arming



- When you try to arm the system and a 24-hour zone² is open, the keypad sounds beeps and the message "Open Zone! Press END or Bypass", with the zone/s details, is displayed in two intermittently changing screens.
- If you do not cancel arming or bypass the open zones, when the Exit delay ends the system will be armed, but the open zones instantly sound the alarm.
- Exit delayed zones are such, so they can be left open until the EXIT delay time ends.

4.2 Prior to arming

- You can temporarily bypass zones in advance of arming the system.



As a precaution, there is a time limit, set by the Installer, for a zone to be bypassed prior to arming. When this time ends and the system has not been armed yet, the zone is automatically reinstated.

² 24-Hour zones sound the alarm whenever they are violated, regardless of the system status.

- To temporarily bypass a zone prior to arming:



```
Bypassed Zone
Back door -14
```

- For example: Zone name Zone number



Be aware that a zone is bypassed immediately and stays so, until the system is disarmed the next time (unless bypass limit time is over).

- To reinstate a bypassed zone:



```
Activated Zone
Back door -14
```

- For example: Zone name Zone number

5 "HOME 1" & "HOME 2" ARMING MODES (KEYS 4, 7)

- "HOME 1" and "HOME 2" are arming modes, in which only some zones are armed, while others are not: while the armed zones sound the alarm if violated, the disarmed zones can be occupied at the same time.
- Common applications for the Home modes are perimeter detectors and nighttime zones.
- The zones included in each Home mode are set by the Installer and require no hardware installation.
- Arming to the Home modes is much like arming to full mode, and there is fast arming option too.

- To arm to "HOME 1" mode: ^{HOME 1} 4 For HOME1 Arming Enter Code User/Short code


```
Home 1 Arming..
Exit Delay 60
```

- To arm to "HOME 2" mode: ^{HOME 2} 7 For HOME2 Arming Enter Code User/Short code

```
Home 2 Arming..
Exit Delay 60
```

- To arm to the Home modes via the User menu: **0** (PROG.) **User code** **4** (HOME 1) for "Home 1" or **7** (HOME 2) for "Home 2".
- The Exit delay for both Home modes can be cancelled by the Installer.

6 DISPLAYING TYPES (KEY #5)



- Your keypad has few options for displaying information on zones, alarms, faults etc.
- There are two basic displaying types: single screen and scrolling.
- Other types display various information for a minute, before they return to one of the basic types.
- Zone names are programmed by the Installer.

6.1 Fast 32-zone display



- This display type is best used in systems with up to 32 zones. Each line displays 16 zones.
- The zones are displayed in a single screen, with their status represented by signs and letters.
- Each sign appears next to the related zone number, which is printed above & below the keypad screen. See Figure 1.
- If the number of zones is no more than 16, information in the top line includes time, date and system status. If the system is configured with more than 16 zones, this information will not be displayed, but the other 16 zones.




Figure 1. Fast zone mode with 16 zones

- The system indicators on the top line (between the time and the date) are:

Indicator	Description
P	The system is communicating or testing the phone line
T	The system is communicating over the Radio
R	The RELAY output is active
S	The SIREN output is active

- The zone status indicators are:

Indicator	Description
–	Closed (not triggered) zone
■	Open (triggered) zone. If the zone has more than one status (e.g., it is open and alarming), the indications are displayed intermittently.
A	Alarmed zone: the zone was violated when the system was armed, or is alarming now.
B	Bypassed zone
C	Chime zone
F	Zone failure (disconnection) or a TAMPER switch is open
L	Low battery in a wireless detector
O	Opened 24-hour zone or armed partition. Press # to display the armed partitions.
S	Short in the zone's wires
T	The zone is in soak (test) mode
V	A wireless detector is not responding

6.2 Scan open zones



- The system continuously scans the zones and the system's status, and displays open zones, faults and alarms.
- The information is displayed in scrolling mode.
- For example:

7 JUN 10 06:33 OP:Zone 13	14 SEP 10 07:15 Low Battery
------------------------------	--------------------------------

Zone #13 is open Low battery

- The zones' status indicators are:

Indicator	Description
OP	Open zone
AL	The zone was violated when the system was armed, or is alarming now.
BP	Bypassed zone
FL	Zone Cut
SH	Zone Short
SV	Zone supervision
LB	Wireless zone low battery
AM	Anti-mask zone

6.3 Disable zone displaying



- The zones' status is not displayed, only alarms and faults (if there are any).

6.4 Other displaying types


- Press **NEXT** to the next displaying types.
- The other types display various information. After pressing **ENTR** the information is displayed for a minute.
- See the display types menu in the beginning of section 6.

6.4.1 All Zones



- The properties of every programmed zone - name, partitions and type - are displayed when pressing **ENTR** repeatedly.

6.4.2 Bypassed Zones



- Permanently and temporarily bypassed zones are displayed in this type.
- Permanently bypassed zones are set by the Installer.
- Temporarily bypassed zones will be automatically reinstated the next time the system is disarmed.

6.4.3 Soaked Zones

to display other soaked zones - **OR** - **ENTR** repeatedly to display the zone's name, partitions and type.

- A zone is set as Soak (test) zone by the Installer/Service technician, when it is repeatedly faulty.
- Soak zones, as well as soak period (up to a week), are set by the Installer/Service technician.
- Soak zones are automatically reinstated when the soak period is over.

6.4.4 Chime Zones

to display other chime zones - **OR** - **ENTR** repeatedly to display the zone's name, partitions and type.

- Chime zones trigger the keypad chime when opened.

6.4.5 All Zones Status


- This type is intended to display the status of all the programmed zones quickly.
- It is design the same as the "Fast zone" type, 10 zones in each line, and 20 in every screen. See section 6.1 for details on the signs.
- In the above screenshots, the first screen displays the status of zones 1 - 10 and 11 - 20. Statuses for example are:
 - Zone #1: chime zone.
 - Zones #2-3: closed zones.
 - Zones #4-6: open zones.
 - Zone #7: chime zone.
 - Zone #8: bypassed zone.
 - Zones #9-10: closed zones.
 - Zone #12: zone fault.
 - Zone #15: zone activated the siren.
 - Zone #22: chime zone.
 - Zone #34: bypassed zone.

6.5 Show partition names




- This is a toggle display type: when it is enabled, the names of the partition/s (see section 12.1 for details) this keypad is allocated to, are constantly displayed.
- To disable this mode, repeat the process.
- This mode requires the “Scan Open Zones” display mode to be selected first.

7 PHONE NUMBERS, SMS SETTINGS & DIALER TEST (KEY 6)



- Key #6 has three sub-menus:
 - “Edit Numbers”, to set your phone numbers for receiving alarms and other messages from the system;
 - “SMS Settings”, to set which of your phones will receive SMS messages instead of alarm messages;
 - “Test dialer”, for testing the numbers you have programmed (without triggering the sirens);

7.1 Phone numbers




- The HUNTER-PRO Series & the Captain 8 have an integrated phone dialer, that can call up to 4 numbers and sound an alarm, or send SMS alert or sound a recorded message.
- When an alarm is set off, the dialer attempts to call each number twice (i.e., a total of 8 attempts)³; when the call is answered, the system sounds a Hi/Lo siren, or a voice message⁴.
- To set a number, enter it and **ENTR**
- To use “+”, “*”, “#” and “P” for one second delay: ***** repeatedly

³ SMS messages are sent only once to each number.

⁴ This feature requires the purchasing of the VU-20 voice module.


- The dialer aborts the dialing attempts in the following cases:
 - The system is disarmed.
 - All numbers were dialed, each number twice (i.e., no call was answered).
 - In HUNTER-PRO Series only, a remote control command is received. See section 14.1.

7.2 SMS messages




- Text messages are an alternative way for you to receive alarms and faults reports.
- The numbers 1-4 stand for the corresponding phone numbers.
- A phone number that is set here to receive SMS messages will not receive the siren alarm.
- For example,  phone #2 will receive SMS messages.
- Sending SMS messages requires the purchasing of the SMS-100 module or the GSM-200 cellular module.

7.2.1 A demo SMS message



- The details in the SMS messages are all taken from the system log.
- In this figure, the time and date indicate when the event was registered in the log, and not when the message was sent.


7.3 Dialer test



- Use the Dialer test menu to check the programmed phone numbers.

- Press a number between 1 and 4 to call the corresponding programmed number.
- If a call is not received, check that the number is correct; if it is, call a service technician.
- During the test, the system displays the communication process, as displayed above.

8 SETTING TIME AND DATE (KEY 8)



- **NEXT / BACK** to move to the left and right.
- To correct data, **END** and start over.
- You must keep the system's clock accurate at all times, for maintaining a detailed log and for functions such as user disarming time frame.
- If the clock is not set, a "Clock Not Set" error is displayed and the keypad beeps.

9 CODES (KEY 9)

- Codes in the Hunter-Pro Series and Captain 8 systems are made of 4-6 digits (except for the Short code).
- Duplicate codes or codes that start with same two digits as the Short code are not allowed.
- Codes are concealed with asterisks and cannot be revealed or restored in any way.


9.1 The Master Code



The default Master (5555) should be replaced immediately after installation (see how in this section).

- The Master code is a super user code, with all access authorizations. See section 1.6.1 for more details.
- Its main use is changing the Master code itself.

9.1.1 Changing the code




- The “Master code” menu is visible only when entering the User menu with the Master code.
- Therefore, to change the code, you can only use the Master code.
- When entering the User menu with a User code and pressing “9”, the “User Codes” menu is displayed.

9.2 User codes

- See section 1.6.2 for details about user codes.


9.2.1 Adding or change a code



- An asterisk (*) appears to the right of the user’s name, notes the user code has been assigned to this user. For example, “Linda” is user number 16:


```
Linda (16) *  
ENTER/NEXT/END
```

9.2.2 Deleting a code




- Once a code is deleted, the asterisk is deleted too and the code is available to be used for another user.

9.3 User name



9.4 User settings




- **NEXT** / **BACK** to move to the left and right.
- **#** (RESET) to set to "+" or "-" (toggle mode): "+" means the user is authorized to perform this action; "-" means the user is NOT authorized to perform this action.
- **ENTR** to save.
- The user settings determine the user authorizations to enter menus and change data, or receive system information.
- Each letter stands for a different authorization. The letters and authorizations are:


Letter	Onscreen	Set to "+", so the user will be...
U	Code Programming	Authorized to set/change user codes
T	Tel. Programming	Authorized to set/change phone numbers
C	Date Programming	Authorized to set/change time and date
M	Memory view	Authorized to view the memory log
B	Zone Bypass	Authorized to temporary bypass zones
K	Use any Keypad	In a system that uses partitions, the user can use any keypad, regardless of the partitions the keypad is assigned to (by the Installer).
A	Auto-arming Prog	Authorized to set/change the auto-arming time
O	OP/CL Report-SMS	Authorized to receive SMS reports, anytime the system is armed and disarmed
R	Remote control	In Hunter-Pro Series only, authorized to control the system remotely, via the phone
W	RFID tag + Code	Required to enter the user code, when disarming with RFID tag/keychain (as a precaution).

- If a user tries to enter a menu it is not authorized to, an "Access Denied" message is displayed.


9.5 Disarming Time Frame



- **NEXT** / **BACK** to correct data.
- A user can be limited to disarm the system only inside a time frame. Arming, however, is not restricted.
- If the user tries to disarm the system in any other time, the message "Access Denied! Press END" is displayed and the system remains armed.
- For example, the user "James D." can disarm the system only between 07:30-09:30:




9.6 User's partitions



- **NEXT** / **BACK** to move to the left and right.
- **RESET #** to assign the user to a partition (set to "+"), or cancel its assignment (set to "-").
- **ENTR** to save.
- Setting a letter to "+" means, the user is authorized to arm and disarm that partition.
- Setting a partition to "-" means, the user will NOT be able to arm and disarm that partition.
- The partition's number is printed on the keypad, below the screen.
- There can be up to 16 partitions in Hunter-Pro Series, 4 in Captain 8. See section 12.1 for details about partitions.
- To enable a user to control its partitions from any keypad (and not just the keypads that are assigned to the partitions its assigned to), see parameter "K" in the "User Settings", section 9.4.

9.7 Adding a key fob




- The key fob is assigned per user, so any use of it is logged under the user code.
- The letter "K" in the user code screen indicates that the User has a key fob assigned to it.

For example, Martha is assigned with a key fob:




- The use of the key fob is subject to the user's settings. See section 9.4.
- For more details on key fobs, see section 12.2.

9.8 Deleting a key fob




9.9 Adding RFID tag/keychain




Bring the keychain or tag near the left side of the RFID keypad (where the RFID reader is located, inside. See the next illustration), until a confirmation message "TAG Received! Press END" is displayed **ENTR**

- The letter "A" in the user code screen indicates that an RFID tag/keychain is assigned to that user. For example,




- To force the user to enter its code when it disarms the system using an RFID tag/keychain, see the "User Settings" in section 9.4.

9.10 Deleting RFID Tag




9.11 The DURESS code




- For details on the DURESS code, see section 2.2.1.

9.12 The Short code



- The Short code is a 2-digit arming only code.
- Entering the code sets off the Exit delay, after which the system is being armed.

9.13 The Door code



- The door code is mainly used for opening electric doors and gates, but can be used to set off anything that is triggered by a RELAY.

10 AUTOMATIC ARMING (KEY 9)

- The Hunter-Pro Series & Captain 8 systems offer two ways to arm the system to full mode automatically: by day and hour, or by lack of activity.
- Automatic arming can be used once a day only.

10.1 By day and hour

PROG. 0 User code PROG. Auto Arm By Day ENTER/NEXT/END Auto Arm By Day Sunday 00:00
 the time for the auto-arming in the following format hh:mm -OR- ENTR
 set a different day ENTR

- You can set the system to be automatically armed every day, at a certain hour.
- At this time, a special 45 seconds delay will start and the keypad will sound beeps. When the delay ends, the normal Exit delay will start and then the system will be armed to full mode.
- The Installer can program the system, so the auto-arming will arm the system to "Home 1" mode instead of full.

10.1.1 Inactivity auto-arming

PROG. 0 User code PROG. Auto Arm By Day ENTER/NEXT/END NEXT InactivityToArm ENTER
 InactivityToArm 0 Minutes inactivity time in minutes (up to 250) ENTR Inact. Per Part ++++++
 set the partitions that will be armed ENTR

- NEXT / BACK to move to the left and right.
- RESET # to select a partition (set to "+"), or deselect it (set to "-").
- ENTR to save.
- The system can be automatically armed, after a period, in which no detector was activated, i.e., the premises is probably vacant and the alarm system was not armed.
- This feature can help you ensure, that the premises will always be armed when it is no longer occupied, e.g., during the night.
- This feature can be set per partition, so some partitions can be armed automatically, while others are not.
- When "Inactivity to Arming" time is due, the partitions that are about to be armed (or are already armed) are displayed as "X", above the partition's number. See the next example.
- A sample auto-arming countdown screen: "45" is the auto-arming delay; "X" are partitions that are either armed or about to be armed automatically: 2, 7-9.

```

Auto Arming - 45
X  XXX
1  2  3  4  5  6  7  8  9  10 11 12 13 14 15 16
    
```

- When the auto-arming delay ends, the Exit delay starts, after which the system is armed.



The Installer can enable auto-arming with open zones and faults.

11 THE CHIME FEATURE (KEY #)



ENTR to assign the chime to the zone **-OR-**

to cancel a zone assignment

- The chime helps supervising the opening of doors and windows by sounding a series of beeps, anytime one of them is opened.
- This feature is especially useful with small children in the house and in shops.
- The chime is active only when the system is disarmed.
- The letter "C" in the "Fast zone" display type indicates the chime is assigned to that zone.

11.1 Enabling and disabling the Chime globally

- Pressing the CHIME * key for 2 seconds enables and disables (toggle mode) the chime globally, to all the chime zones.
- A verification message, "Chime ON"/"Chime OFF", is displayed.

12 OTHER TOPICS

12.1 Partitions

- A partition (or sub-system) is a logic or physical area, made of several zones, e.g., a separate compound, a house floor, an office, a perimeter zone.
- A partition can be armed, while others (i.e., other zones) are not. In this way, only those zones that are allocated to the armed partition/s will activate the alarm, when they are opened; zones outside the armed partitions can be occupied at the same time.
- Partitions are programmed by the Installer.
- There can be up to 16 partitions in Hunter-Pro Series and 4 in Captain 8.
- Monitored keypads can also be assigned per partition.
- Users can also be allocated to partitions, i.e., control (e.g., arm & disarm) only some of the zones.

12.1.1 Examples

Example A: private premises, single keypad




Figure 2. Implementing partitions - Example A⁵

- In this example, a single keypad controls all 3 partitions
- The users are all assigned to all 3 partitions and can therefore control them all.



A user can control several partitions using a single code.

Example B: private premises, 3 keypads




Figure 3. Implementing partitions - Example B

- The system is divided into partitions, each controlled by a separate keypad. The users have authorization levels based on partition/s, e.g., user 12 can only control Partition #3 & #14.
- Every keypad displays the status of its assigned partitions only.

⁵ Published under 'Creative Commons' license (source: <http://www.flickr.com/photos/axiomestates/3081558445/>)

Example C: variable options⁶



Figure 4. Implementing partitions - Example C

- In a 3 floors building, the first floor is defined as Partition #1, the second as Partition #2 and the third as Partition #3. There are 3 users and 3 keypads, with different authorization levels:
 - User #2 is authorized to use all three keypads;
 - User #4 is authorized to use only keypad #1, which controls and displays partition #2 only;
 - Users #1 & #2 are authorized to use only Keypad #2 which controls and displays all 3 partitions;
 - User #3 is authorized to use only keypad #3 which controls and displays partition #3 only;

Example D: office compound




Figure 5. Implementing partitions - Example D

- A compound is made of 16 offices; each is located in a separate room. Each room is assigned as a partition and can be controlled by different users, remote controls, key switches and RFID tags.
- The single keypad in this example will display the status of all partitions, though the users will only be able to control their authorized partition/s.
- A detector located at the entrance and allocated to all partitions protects the entrance, as soon as all partitions are armed. This detector will be disarmed as soon as the first partition is disarmed.

⁶ Published under Creative Commons license (source: <http://awkwardfamilyphotos.com/wp-content/uploads/2009/07/shari-awkward-plaid-family-photo.jpg>)

Example E: business installation





Figure 6. Common application for partitions

- The headquarters of a company is divided into 4 departments: each has its own keypad, employees, working hours, etc.
- The employees (i.e. users) can have access only to their department/partition, or to several.

12.1.2 Displaying armed partitions

- The Installer can enable the displaying of the status of the partition.
- Armed partitions are displayed with "X", above the corresponding number.



12.2 Arming with key, key fob or RFID tag/key chain

- You can arm your system using key switch, key fob and RFID tag/keychain.
- The three accessories are assigned per user.
- A key switch requires no other module and is used mostly in businesses.
- Key fobs require the installation of a wireless module, the I/O-WN that supports up to 24 key fobs. The module can be purchased from your Installer.
- RFID tags and key chains require the use of RFID keypad. The keypad can be purchased from your Installer. Depending on your system model, up to 32/96/144 RFID users can be supported.

12.2.1 Arming with a key fob




Figure 7. The MCT-234 key fob

- The Visonic MCT-234 key fob has 4 push buttons. Pushing each button, or a combination of two, performs the next actions:

Action	Push button/s
Arm to full mode	
Arm to "Home 1" mode	
Arm to "Home 2" mode	 + 
Disarm	
Generate PANIC alarm	 + 
Trigger one of the system's outputs (to open a gate, turn on a spotlight, etc.)	

- Up to 24 key fobs can be assigned to users.

12.3 Enabling Remote Upload

- Your alarm system can be uploaded (i.e. programmed) remotely, by a service technician, over the phone line or the network.
- For security reasons, this feature is disabled by default. If the technician needs to use it, you have to approve it.
- To do so: just before the technician calls the system, enter the Master code (only the Master code can enable it) and press **ENTR** twice.

12.4 Names and Characters

- Names and characters are entered the same way as in cell phones: each key has letters and characters associated with it.



- A Username can have up to 8 characters.
- Each arming & disarming is registered in the memory log along with the user name, date and time (see section 3).
- The number of keystrokes determines which character is selected.
- To enter some characters using the same key, wait 2 seconds between each keystroke.
- For example, key **6** is used for typing the letters M, N, O and number 6. To select "M", press the key once; to select "O", press the key three times.
- See the keys and their associated characters in the next table.

Keystrokes								
Key	1	2	3	4	5	6	7	8
[1]	.	,	?	!	1			
[2]	A	B	C	2				
[3]	D	E	F	3				
[4]	G	H	I	4				
[5]	J	K	L	5				
[6]	M	N	O	6				
[7]	P	Q	R	S	7			
[8]	T	U	V	8				
[9]	W	X	Y	Z	9			
[0]	Space	0						
[*]	()	/	*	:	-	+	#
[#]	Uppercase/Lowercase letters (toggle)							
[END]	Cancel/Return to previous screen without saving							
[NEXT]	Next character							
[BACK]	Previous character							
[ENTR]	Select/Save							

12.4.1 Example

- The following demonstrates writing the word "KITCHEN":

Key	Keystrokes	Character	
[5]	2	K	NEXT
[4]	3	I	NEXT
[8]	1	T	NEXT
[2]	3	C	NEXT
[4]	2	H	NEXT
[3]	2	E	NEXT
[6]	2	N	ENTR

12.5 PANIC alarm



- To manually generate a PANIC alarm, press and hold for 2 seconds (until a confirmation tone is sounded), the Asterisk and the Hash Keys.
- PANIC alarm is immediately reported to the Monitoring Station (if you are a subscriber) and your phones.
- In addition to activating the sirens, the Installer can set the system to response in various ways.



12.6 Resetting Smoke/Fire/Anti-mask detectors

- Smoke, Fire and Anti-mask detectors need to be reset if they are activated.
- They can be reset automatically or manually. To manually reset them:  **#** (press and hold the hash key for 2 seconds, until a confirmation tone is sounded).

12.7 Turning the keypad chime ON/OFF

 **END** + **ENTR**

- Pressing these keys together turns the keypad's chime ON/OFF (toggle mode).
- Note that turning the chime off disables vocal indication of faults and opening Chime zones.
- The chime is set separately in each keypad.
- To silence the chime in case of faults,  **END**

12.8 Comparison between the Hunter-Pro Series models


Feature	Hunter-Pro		
	832	896	8144
Zones (8 basic)	32	96	144
Users	32	96	144
Partitions	16	16	16
Wireless zones	24	32	32
Key fobs	24	24	24
Memory total	500	500	999
of which non-volatile	250	250	512

12.9 Comparison between the Hunter-Pro 896 & Captain 8

Feature	Captain 8	Hunter-Pro
Zones (using expanders)	16	96
Zone doubling (of the onboard zones)	√	√
Keypads	8	8
Partitions	4	16
EXP-PRO	-	√
I/O-8N/PS	1	11
I/O-16/PS	-	5
Outputs	12	58
of which onboard	3	7
OUT-1000	-	√
I/O-R	1	4

Feature	Captain 8	Hunter-Pro
I/O-WN	√	√
Wireless zones	8	32
Key fobs	24	24
Users	30	96
RFID tags	30	96
VVR devices	1	4
Events Log	160	500
of which non-volatile	128	250

13 MANUAL SYSTEM TESTS (BACK KEY)



- The system constantly tests the backup battery, the voltage and the phone line. However, you can perform a manual test too.
- A manual test is reported to the Monitoring Station.
- If the tests fail, the following messages appear:



If your alarm system is connected to a Monitoring Station via Ethernet or GPRS, some additional test screens are displayed.

14 REMOTE CONTROL VIA THE PHONE



- **Remote control is not available in Captain 8.**
- **This section refers to Hunter-Pro Series only.**

- The Hunter-Pro Series alarm system can be remotely controlled via any touchtone or cellular phone.
- A remote control call can be initiated by both calling the panel and receiving a call from the panel.
- There are two modes to remote control (they are set by the Installer):
 - Basic mode: includes arming, disarming, deactivating the sirens, and more. That's the default mode;
 - Full mode: includes the basic mode and in addition, activating RELAY switches.

14.1 Basic mode

- To control the system remotely:
 1. Call the phone number to which the system is connected (or pick a call from the system).
 2. Wait for a confirmation tone: a long tone followed by 2 beeps.
 3. Dial the Master code or authorized User code (see section 9.4);
 4. Wait for a status tone:

Continuous: The system is disarmed;

Beeps: The system is armed;



The system does not recognize phone commands (tones) while sounding the confirmation tone. Therefore, you must wait until the confirmation tone is over, before pressing any phone key.

5. Dial a number, according to the next table. The panel confirms every command with two beeps.

Dial	Action
0	Stop the external siren and the dialer
1	Arm the system
2	Disarm the system (if enabled by the technician)
4	Arm the system to "Home 1" mode
5	Switch on the onboard relay
6	Switch off the onboard relay
7	Arm the system to "Home 2" mode
8	Listen in for one minute (using MIC-200). Any more press will extend the listen in time in one minute

- While the system is communicating, the message "Other keypad in use" is displayed on all the keypads.
- If the panel does not receive any command for a period of 60 seconds, it disconnects the call. It then remains in standby mode (with the above message displayed on the keypads) for another 60 seconds, before the message disappears.
- During listen in, all other remote control commands are disabled.



14.2 Full mode

- To control the panel in full mode:
 1. Repeat steps 1-4 in the previous Basic mode section.
 2. To trigger an output, press [*] and the corresponding command, as listed in the following tables.
 3. To deactivate an output, press [#] and the corresponding command from the following tables.

General	
Command	Dial
Turn off the external siren and stop the dialer	*00
Arm the system	*01
Disarm the system	#01
Arm to "Home 1" mode	*04
Arm to "Home 2" mode	*07
Start listen in for 1 min.	*08

System's outputs	
Output	Dial
Ext. SIREN	11
Int. SIREN	12
RELAY	13
SMOKE	14
ON/OFF	15
ALARM	16
AUDIO Ctrl	17

RELAYS on I/O-8N zone expanders	
I/O-8N	Dial
1	31
2	32
3	33
4	34
5	35
6	36
7	37
8	38
9	39
10	40
11	41
12	42
13	43
14	44
15	45
16	46

I/O-R RELAY expanders			
Expander no. 1		Expander no. 3	
RELAY no.	Dial	RELAY no.	Dial
1	51	1	67
2	52	2	68
3	53	3	69
4	54	4	70
5	55	5	71
6	56	6	72
7	57	7	73
8	58	8	74
Expander no. 2		Expander no. 4	
RELAY no.	Dial	RELAY no.	Dial
1	59	1	75
2	60	2	76
3	61	3	77
4	62	4	78
5	63	5	79
6	64	6	80
7	65	7	81
8	66	8	82

Send SMS message with the system status to your phones	
Phone no.	Dial
1	91
2	92
3	93
4	94

14.2.1 Examples

Activate the 'Ext. SIREN' output:

Dial the panel's phone number → the panel picks up the call → wait for the confirmation tone to end → dial the Master code → wait for command confirmation tone to end → dial *11

Deactivate RELAY#2 in I/O-R #2:

Dial the panel's phone number → the panel picks up the call → wait for the confirmation tone to end → dial the Master code → wait for command confirmation tone to end → dial #60.

15 TROUBLESHOOTING

- Faults are indicated by the flashing red LED in the keypad, a description of the fault is displayed, the buzzer sounds beeps and the system logs it. In addition, the service technician can set the system to report it to the Central Monitoring Station, to send an alert by the telephone, to trigger an output and more.
- If more than a single fault occurs, the display will scroll between them.
- Unless instructed otherwise, call a service technician when the system reports on faults.

Fault	Description and troubleshoot
Low Battery	Occurs after a prolonged power failure or when the battery is outdated. If the fault lasts more than one day, or there was no previous power failure, call a service technician.
Mains Fault	Appears during a power failure.
Clock Not Set	Appears following a prolonged power failure during which the backup battery was completely discharged. Set time and date (see page 19).
Phone Line Fault	Perform phone line test (see Manual System Tests on page 33). Make sure no other telephone appliance is using the line. If the fault persists, call a service technician.
Tamper 1	Tamper switch 1 is open.
Tamper 2	Tamper switch 2 is open.
Expander X Tamper	Expander X's box or tamper is open.
Expander X Fault	Expander X is faulty.
EXP X Voltage	Low voltage to the I/O-8N zone expander.
Expander X Mains	Expander X has no Mains voltage.
Expander X Batt	Expander X has low battery fault.
Keypad X Tamper	Keypad X's tamper switch is open.
Low Voltage	Appears before the backup battery is completely discharged, usually during a prolonged power failure. Call a service technician immediately!
Wireless Z Fault	A wireless detector (zone) is faulty (no supervision signal).
MS COM Fault	Failure to communicate with the Central Monitoring Station over the phone.
KEYPAD NOT CONNECTED	No communication between the keypad and the control panel.
GSM Unit Fault	The GSM-200 module cannot be detected or is faulty.
GSM Link Fault	GSM limited or no reception.
GSM Comm. Fault	GSM communication failure with Central Monitoring Station #1.
GSM Comm. 2 Fault	GSM communication failure with Central Monitoring Station #2.
SIM Card Fault	SIM card is not detected or is faulty.
Wireless System	I/O-WN module cannot be detected or is faulty.
W/L Unit Tamper	I/O-WN box tamper is open or faulty.
Other keypad in use	Other keypad is in use or the system is remotely controlled via the telephone.
Check Keypad Number	The keypad's ID is not configured properly.
Keypad X Fault	Keypad X is faulty.
Zone Fault	A zone (include. Wireless zone) is tampered or faulty. Possible tampering!

Fault	Description and troubleshoot
Detec Vol. Fault	Detector voltage is faulty due to possible tampering . Call a service technician immediately!
SMS Com. Failure	SMS communication fault.
Install SMS Unit	No SMS unit is detected or the unit is faulty.
Network Fault	Network communication with the Central Monitoring Station is faulty.
IO-R X Fault	The I/O-R relay expander is faulty.
IO-R X Tamper	The I/O-R relay expander tamper is open.
IO-R X Voltage	Low voltage in the I/O-R relay expander.
IO-R X Mains	IO-R X has no Mains voltage.
IO-R X Batt	IO-R X has low battery.
Wireless Jamming	The wireless receiver (I/O-WN) is jammed.
Supervision	A wireless detector "life signal" has not been received.
Int. siren fault	The internal siren is faulty.
Ext. siren fault	The external siren is faulty.
Video X fault	Communication fault between the panel and the video unit VVR #X.
Video X power fault	Voltage fault in VVR #X.
net4pro fault	Communication fault between the panel and the net4pro network card.

16 APPENDIX: ZONE LOCATION TABLE

No.	Zone	Location
1.		
2.		
3.		
4.		
5.		
6.		
7.		
8.		
9.		
10.		
11.		
12.		
13.		
14.		
15.		
16.		
17.		
18.		
19.		
20.		
21.		
22.		
23.		
24.		
25.		
26.		
27.		
28.		
29.		
30.		
31.		
32.		
33.		
34.		
35.		
36.		
37.		
38.		
39.		
40.		
41.		
42.		
43.		
44.		

No.	Zone	Location
45.		
46.		
47.		
48.		
49.		
50.		
51.		
52.		
53.		
54.		
55.		
56.		
57.		
58.		
59.		
60.		
61.		
62.		
63.		
64.		
65.		
66.		
67.		
68.		
69.		
70.		
71.		
72.		
73.		
74.		
75.		
76.		
77.		
78.		
79.		
80.		
81.		
82.		
83.		
84.		
85.		
86.		
87.		
88.		

No.	Zone	Location
89.		
90.		
91.		
92.		
93.		
94.		
95.		
96.		
97.		
98.		
99.		
100.		
101.		
102.		
103.		
104.		
105.		
106.		
107.		
108.		
109.		
110.		
111.		
112.		
113.		
114.		
115.		
116.		
117.		

No.	Zone	Location
118.		
119.		
120.		
121.		
122.		
123.		
124.		
125.		
126.		
127.		
128.		
129.		
130.		
131.		
132.		
133.		
134.		
135.		
136.		
137.		
138.		
139.		
140.		
141.		
142.		
143.		
144.		

Installer Details:

Name: _____ Phone: _____

Cellular: _____

Company: _____

Phone no.: _____

Date of installation: Day ____ Month ____ Year ____

End of service: Day ____ Month ____ Year ____

PIMA Electronic Systems Ltd. does not represent that its product may not be compromised and/or circumvented, or that the Product will prevent any death, personal and/or bodily injury and/or damage to property resulting from burglary, robbery, fire or otherwise, or that the Product will in all cases provide adequate warning or protection. The User understands that a properly installed and maintained equipment may only reduce the risk of events such as burglary, robbery, and fire without warning, but it is not insurance or a guarantee that such will not occur or that there will be no death, personal damage and/or damage to property as a result.

PIMA Electronic Systems Ltd. shall have no liability for any death, personal and/or bodily injury and/or damage to property or other loss whether direct, indirect, incidental, consequential or otherwise, based on a claim that the Product failed to function.

Please refer to a separate warranty statement found on PIMA website at:

<http://www.pima-alarms.com/site/Content/t1.asp?pid=472&sid=57>

Warning: The user should follow the installation and operation instructions and among other things test the Product and the whole system at least once a week. For various reasons, including, but not limited to, changes in environment conditions, electric or electronic disruptions and tampering, the Product may not perform as expected. The user is advised to take all necessary precautions for his/her safety and the protection of his/her property.

This document may not be duplicated, circulated, altered, modified, translated, reduced to any form or otherwise changed; unless PIMA's prior written consent is granted.

All efforts have been made to ensure that the content of this manual is accurate. Pima retains the right to modify this manual or any part thereof, from time to time, without serving any prior notice of such modification.

Please read this manual in its entirety before attempting to program or operate your system. Should you misunderstand any part of this manual, please contact the supplier or installer of this system.

Copyright © 2011 PIMA Electronic Systems Ltd. All rights reserved.

PIMA Electronic Systems Ltd.

5 Hatzoref Street, Holon 58856, Israel

Tel: +972.3.6506414

Fax: +972.3.5500442

Email: support@pima-alarms.com

Web: <http://www.pima-alarms.com>

Partner's website: <http://www.pima-alarms.com/site/modules/login.asp>

4410280



Version : B2, XX en, September 2011