

SIEMENS



FC1008/12-A/ -B/ -C

Fire control unit

Technical specification

Fire & Security Products

Siemens Building Technologies

Liefermöglichkeiten und technische Änderungen vorbehalten.
Data and design subject to change without notice. Supply subject to availability.
Sous réserve de modifications techniques et de la disponibilité.
© 2003 Copyright by
Siemens Building Technologies AG

Wir behalten uns alle Rechte an diesem Dokument und an dem in ihm dargestellten Gegenstand vor. Der Empfänger anerkennt diese Rechte und wird dieses Dokument nicht ohne unsere vorgängige schriftliche Ermächtigung ganz oder teilweise Dritten zugänglich machen oder außerhalb des Zweckes verwenden, zu dem es ihm übergeben worden ist.

We reserve all rights in this document and in the subject thereof. By acceptance of the document the recipient acknowledges these rights and undertakes not to publish the document nor the subject thereof in full or in part, nor to make them available to any third party without our prior express written authorization, nor to use it for any purpose other than for which it was delivered to him.

Nous nous réservons tous les droits sur ce document, ainsi que sur l'objet y figurant. La partie recevant ce document reconnaît ces droits et elle s'engage à ne pas le rendre accessible à des tiers, même partiellement, sans notre autorisation écrite préalable et à ne pas l'employer à des fins autres que celles pour lesquelles il lui a été remis.

1	About this document	5
2	Safety regulations	7
2.1	Signal words and symbols	7
2.1.1	Classification and meaning of signal words	7
2.1.2	Symbols and their meaning	7
2.1.3	Classification and meaning of additional symbols	7
2.2	Safety-relevant working instructions	8
3	System description	9
3.1	General	9
3.2	Main features	9
3.3	System overview	9
3.4	Technical data	10
4	Installation	11
4.1	Assembly	11
4.2	Mounting	12
5	Function and design	13
5.1	Mainboard hardware settings	13
5.2	Peripheral connections	14
5.2.1	Mainboard	14
5.2.2	Power supply	15
5.2.3	Line bridging at removed detector head	15
5.2.4	Manual call point detection	15
5.2.5	Zone extension module	16
5.2.6	Control line extension card	17
5.2.7	RT-blocking card	18
5.3	Event processing	19
5.3.1	Alarm	19
5.3.2	Fault	19
5.3.3	Processing diagram	19
6	Operation and indicator elements, mode of operation (PMI)	20
6.1	Operating panel	20
6.1.1	General	20
6.1.2	Indicators	21
6.1.3	Operating keys	22
6.1.4	Zone indicators and keys	23
6.2	Display module	24
6.2.1	General	24
6.2.2	Poll event memory	24
6.2.3	Set clock	25
6.2.4	Poll service informations	26
6.2.5	Delete alarm counter and event memory	26
7	Commissioning	27
7.1	Procedure	27
7.2	Testing peripheral devices	28
8	Configuration	29
8.1	Programming user functions	29
8.2	Programming steps	31
8.3	Programmable functions	33
8.3.1	Step 1, timer V1	33
8.3.2	Step 2, timer V2	33

8.3.3	Step 3, zone processing on alarm	34
8.3.4	Step 4, LED activation mode.....	34
8.3.5	Step 5, activation mode of (horn) control lines.....	34
8.3.6	Step 6, measures against false alarms.....	35
8.3.7	Step 7, control lines on alarm.....	35
8.3.8	Step 8, special zone parameters	35
8.3.9	Step 9, zone self hold state.....	35
8.3.10	Step 10, detector line short or break.....	35
8.3.11	Step 11, cross zoning.....	36
8.3.12	Step 12, access code.....	36
8.3.13	Step 13, special PMI parameters	36
8.3.14	Step 14, delay mains failure	37
8.3.15	Step 15, special parameters	37
8.3.16	Step 16, programmable control input.....	37
8.3.17	Step 22, indicating mode display	37
8.3.18	Step 23, switching mode manned/unmanned.....	37
8.3.19	Step 24, display switching time	38
8.3.20	Step 25, switching mode summer/winter time	38
8.3.21	Step 26, switching time manned/unmanned	38
8.4	Log sheet for programmed user functions	39
8.5	Checksum	40
9	Maintenance.....	41
9.1	General.....	41
9.2	Recommended system performance checks.....	41
10	Trouble shooting.....	43
10.1	Interpretation of fault LED flashing.....	43
11	Components and spare parts	44
11.1	Components	44
11.2	Accessories	44
11.3	Spare parts.....	44
12	Disposal and environmental protection	45
12.1	General.....	45
12.2	Disposal.....	45

1 About this document

Purpose and scope

This document describes the installation, function, commissioning, maintenance, troubleshooting and disposal of the product FC10xx. The consistent observance of the instructions ensures a trouble-free and safe application.

Application area

The information in this document applies from the hardware / software version 5.x.

Target group

This documentation and the instructions therein are intended for the following group(s) of persons who perform the tasks mentioned and have had the corresponding training.

Group of persons	Activity	Qualification
Product Manager (PM)	He is in charge of local product management and is responsible for the interchange of information between the plant supplying the equipment and his DU for his product line. He co-ordinates the flow of information between the individual groups of people for the various projects.	He has had training appropriate to his function and product range and has attended the product manager training course.
Project Manager	The project manager is responsible for the local project management. He co-ordinates the schedules of all groups of people working on a project as well as resources. He also continuously obtains the technical information required for project realization.	He has had the technical training appropriate to his function and the size of a project or the product line used in the project and has attended the training courses for project managers at the supplier's works.
Project Engineer	Provides the parameterization of products, devices and systems in the DU for a specific country or customer. He monitors the serviceability and gives the go-ahead for the commissioning of products, devices and systems at the place of installation. He is also responsible for trouble-shooting.	He has had the training appropriate to his function and to the products, devices and systems to be parameterized and has attended the technical training courses for project engineers at the supply plant.
Commissioning personnel	The configuration of the products, devices or systems for specific customers at the place of installation. They check serviceability and officially clear the product, device or system for use by the operator / customer. They are also responsible for trouble-shooting.	They have had the training appropriate to their function and to the commissioning of the products, devices or systems and have attended the technical training courses for commissioning personnel.
Maintenance Personnel	They carry out all the maintenance work indicated in the product documentation and check equipment for total serviceability.	They have had the technical training appropriate to their function and the product.

Operational and safety regulations



Before groups of persons begin work on the system they must have read and understood the related documents, in particular Chapter 2 *Safety regulations*.

Disregard of the safety regulations

The products are designed for an appropriate use and were tested for faultless functioning. Siemens disclaims all liability for damage or personal injuries caused by the incorrect application of the instructions or disregard of warnings of danger contained in the documentation. This applies in particular to:

- Personal injuries or damage caused by improper use and incorrect use;
- Personal injuries or damage caused by disregarding information relevant for safety in the documentation or on the product;
- Personal injuries or damage caused by poor maintenance or a lack of maintenance.

Reference documents

Number/Version	Name
005001	Operating Manual
004656	Product data sheet FC10

Download

The most recently released technical documentation for customers can be found in the Siemens Intranet under the following address: <http://web4.cerberus.ch/>.

Standard symbols

→	Result, note
<i>Text in italic</i>	Quotation, exact match
→ see	Cross reference
(...)	Brackets contain supplementary text, suggestions etc.

Abbreviations

Abbreviation	Explication
DU	Divisional Unit
EOL	End of line element
LED on, slow, fast	LED on, flashes slowly, flashes fast
NC / NO	(Contact) normally closed / normally open
PMI	Person Machine Interface (operating panel)
RT	Remote transmission

Document identification

Position	Signification
Title page	<ul style="list-style-type: none"> – System names – Product type – Purpose of the document
Last page bottom left	<ul style="list-style-type: none"> – Document number – Date of edition
Last page bottom right	<ul style="list-style-type: none"> – Manual – Register

Modification index

Version	Date	Brief description
005000_c_en_--	11.2003	First edition FC10
005000_b_en_--	11.2002	Update to version 4.2 Chapter 5.1; jumper PU11 Chapter 5.3.2; new LED 17 Chapter 5.3.3; additional function of key 11 Various programming extensions
005000_a_en_--	05.2002	First edition BC10

2 Safety regulations

This chapter describes the danger levels and the relevant safety regulations applicable for the use of our products. Please read the work instructions as well as the chapter *About this document* thoroughly before beginning any work.

2.1 Signal words and symbols

2.1.1 Classification and meaning of signal words

The danger level – that is, the severity and probability of danger – is indicated by the signal words listed below. Non-observance may lead to the consequences indicated:

DANGER!	Imminent danger! ● May cause danger to life or serious bodily injury!
WARNING!	Dangerous situation! ● May cause serious bodily harm.
CAUTION!	May cause dangerous situations! ● May cause light injuries!
NOTE!	Possibly harmful situation! ● May cause damage to the product or to objects in the immediate vicinity of the product!

2.1.2 Symbols and their meaning

The symbols listed below indicate the nature and origin of the danger.



General danger



Electrical voltage

Examples of danger warnings

The example below illustrates the appearance and form of danger warnings in our documents.



DANGER

External voltage

Disconnect the module from the power supply.

2.1.3 Classification and meaning of additional symbols



Tips and information



Refers to extremely important or critical decisions to be taken into account before continuing the work.

2.2 Safety-relevant working instructions

Country-specific standards

The products are developed and produced in compliance with the relevant international and European safety standards. Should additional country-specific, local safety standards or regulations concerning project planning, mounting, installation, operation and disposal of the product apply in the place of operation, then these standards or regulations must also be taken into account in addition to the safety regulations mentioned in the product documentation.

Electrical installations



DANGER

Work on electrical installations

Any work on electrical installations may only be carried out by qualified electricians or instructed persons working under the guidance and supervision of a qualified electrician, in accordance with the electrotechnical regulations.

- Control units must be disconnected from the power supply during commissioning or maintenance work.
- Terminals with an external voltage supply must be provided with a sign *DANGER - External voltage*.
- Mains leads to the control unit must be installed separately and provided with a clearly marked fuse.
- Earthing must be carried out in compliance with local safety regulations.

Assembly, installation, commissioning and inspection work

- If any tools or accessories such as ladders are required, safe and suitable devices must be used.
- Prevention of spurious tripping of the remote transmission must be assured.
- Always inform the fire brigade before testing the remote transmission.
- The activation of fire control installations for test purposes must not cause damage to the system or parts thereof.
- Fire control installations must only be activated after the test has been completed and the system has been definitely handed over to the customer.
- Third party systems or devices must only be activated in the presence of the responsible person.

Modifications to the system design and the products

Modifications to a system or to individual products may cause faults or malfunctioning. Please request written approval from us and the relevant authorities concerning intended system modifications and system extensions.

Modules and spare parts

- Locally procured modules and spare parts must comply with the technical specifications laid down by the manufacturer. This compliance is always ensured for original spare parts supplied by us.
- Only use fuses with the specified fuse characteristics.
- Wrong battery types and improper battery exchange may lead to explosion risk. Only use the specified battery type or an equivalent battery type recommended by the manufacturer.
- Batteries require environmentally safe disposal. They must be handed in at the local collecting points.

3 System description

3.1 General


A conventional fire detection control unit for unconventional function characteristics. The FC10 has all the functions that are necessary to build up small and medium size fire detection systems in a very efficient way.

Control unit variants	
8 zones:	12 zones:
<ul style="list-style-type: none"> ● FC1008-A «STANDARD» ● FC1008-B «GB» ● FC1008-C «NORDIC» 	<ul style="list-style-type: none"> ● FC1012-A «STANDARD» ● FC1012-B «GB» ● FC1012-C «NORDIC»

3.2 Main features

- Microprocessor-controlled fire detection control unit
- For collective fire detectors
- Programmable parameters for
 - alarm organization
 - alarm verification
 - cross zoning
 - horn control lines
- Processing technical alarms
- Optional: Display for alarm counter, clock, event memory etc.
- Programming on site via operating panel
- Emergency power operation up to 72h
- Compliance with EN54

3.3 System overview




3.4 Technical data

Collective lines (zones)	8 or 12
Number of detectors per line	max. 32
Compatible detector series	– <i>Cerberus</i> (DS1100, MS24, MS9, MS7, MS6) – <i>Standard</i> (Synova Series 300)
Ratings detector line	
Operating voltage / quiescent current	18 ... 22V / max. 3.2mA
Line resistance / capacitance	
– Type <i>Cerberus</i>	$\leq 80\Omega$ or $\leq 50\Omega$ / $\leq 1\mu\text{F}$ 1)
– Type <i>Standard</i>	$\leq 100\Omega$ or $\leq 50\Omega$ / $\leq 1\mu\text{F}$ 1)
Alarm criteria	
– Type <i>Cerberus</i>	17.5 ... 39mA and $> 5.1\text{V}$
– Type <i>Standard</i>	17...83.6mA
Alarm-Trigger	
– Type <i>Cerberus</i>	resistor 820 Ω or Z-diode 5.6V, 2)
– Type <i>Standard</i>	resistor 820 Ω or Z-diode 5.6V, 3)
Line termination	
– FC10xx-A/ -C	resistor 3k9
– FC10xx-B	EOL FCE1003-B
Monitored control lines	2 + 4 optional
Voltage/current in state active	24V max. 500mA per per line
Line termination	EOL FCE1002
Potential –free contacts	1 x Alarm, 1 x Fault / max. 1A/30V
Control inputs	6 x 24V switched via contact
Fire control outputs	6 + 1 per zone / max. 40mA/24V
Fire control relays	max. 6 (optional) / max. 10A/230VAC
Power supply	
Mains voltage	115/230VAC; +10% / -15%
Power consumption	25 ... 45VA
Secondary power (current low voltage side)	max. 1.5A
System supply voltage	21 ... 28VDC
Emergency power	
Operation time	max. 30h (12Ah) or max.72h (15 - 18Ah)
Battery size	2 x 12V/12Ah or 2 x 12V/15 - 18Ah, lead acid
Quiescent current	
– 8 zones	125mA
– 12 zones:	155mA
– with additional control line extension card	84mA
– with additional display module	7.5mA
Alarm current per zone	+ 30mA (without current of external alarm devices)
Battery low discharge cut off	<18.5VDC
Charging temperature compensated	yes
Cabinet	
Assembly	metal frame with plastic cover
Color	metal frame grey RAL9006 / cover white RAL9003
Protection degree	IP40
Dimension (W x H x D)	506 x 378 x 125mm
Temperature range (operation)	0 ... 50°C

- 1) Line resistance $\leq 50\Omega$ if option 4 is selected in step 3 and option 8 is selected in step 15.
- 2) Use 5.6V z-diode if option 4 is selected in step 3 and option 8 is selected in step 15.
- 3) Use 5.6V z-diode if option 4 is selected in step 3 and option 8 is selected in step 15. In all other cases, use 820 Ω resistor or standard call point with integrated alarm detection.


4 Installation

4.1 Assembly



Pos	Components
1	Mains connection and circuit breaker (fuse), factory mounted
2	Mainboard
3	Nock-outs for cable entries 20mm; top 17, bottom 3
4	Display module (option)
5	Line extension card, FC1012 only
6	Control line extension card (optional) under Line extension card
7	Batteries
8	Key switch Nordic (variant Nordic only) or key switch set (option)
9	Power supply card
10	Optional fire control relays

4.2 Mounting



Procedure


1. Remove front cover
2. Determine mounting location (not behind a door)
3. Mark position of mounting screws (use enclosed drilling template) and drill holes.
Installation accessories not included in cabinet:
 - screws min. 4x50mm
 - plastic dowels
 - c-shaped washers or lock washers
4. Mount chassis, if required with distance sleeves (1)
5. Break out cable entries (3) and mount cable glands (PG11) if required (2)
6. Insert inscription stripes (4)
7. Remove the recess (5) if optional key switch is used
8. Insert batteries (6)
9. Connect all periphery devices (refer to page 14 – 18)
10. Set jumpers on main board (refer to page 13)
11. Commission system (refer to page 27)
12. Adapt the user functions where required (refer to page 29 – 38)
13. Mount front cover



Protect the mounted unit with its shipping carton during construction phase by using the shipping carton

5.2 Peripheral connections

5.2.1 Mainboard




Detector and control lines that are not used must be terminated

• detection line with FC10xx-A /-C	resistor 3k9
• detection line with FC10xx-B	EOL FCE1003-B
• control line	EOL FCE1002


Inputs	Function / Application		Remarks
Detector lines 1 - 8	– to process collective detectors – various parameters (see programming user functions)		
Control inputs			
Reset	to reset system on <i>Alarm</i> (pulse); optional also on <i>Fault</i>		– for internal and external use – inputs always accessible (independent from state operating access provided at the PMI)
Ack	to acknowledge system on <i>Alarm</i> and <i>Fault</i> (pulse)		
Programmable	→ see programming step 16		
Fault	to initiate general Fault as long as positive potential is applied		
Fault-RT	to initiate RT-Fault as long as positive potential is applied		
Access to PMI	to provide operating access as long as positive potential is applied		
Outputs	Function / Application	Load / rating	Remarks
Power output 24V	To provide minus and positive potential for driver outputs and control inputs	– max. 500mA – short circuit proof	for internal and external use
Control lines Alarm devices	– To activate alarm devices (horn or flash light) – active on Alarm 1 and Alarm 2 until <i>Acknowledge</i> or <i>Reset</i> – various activation modes programmable → see programming step 5	– max. 500mA/24V – short circuit proof	
Relay contact <i>RT-Fault</i>	– To provide state <i>Fault</i> to 3rd party systems – active on <i>RT-Fault</i> until Acknowledge – blocked with <i>RT-Fault</i> disabled	– max. 1A/30V – type of contact NO or NC	– NO/NC programmable via jumper PU10 – also activated on system fault
Relay contact <i>RT-Alarm</i>	– To provide state <i>Alarm</i> to 3rd party systems – active on <i>RT-Alarm</i> (Alarm 2) until Reset – blocked with <i>RT-Alarm</i> disabled	– max. 1A/30V – type of contact NO or NC	NO/NC programmable via jumper PU11
Driver outputs			
Mode manned	active if system is in mode manned	– max. 40mA/24V – short circuit proof	for internal and external use
Alarm 1	active on <i>Alarm 1</i> (inactive on Alarm 2)		
Alarm 2	active on <i>Alarm 2</i> until Reset		
Disable	active if any part of the system is disabled		
Fault	active on <i>Fault</i> until restored		
Alarm 1/2	active on <i>Alarm 1</i> and <i>Alarm 2</i> until Reset		
Zone 1 - 8	Active on zone alarm, or zone fault, switched off or test → see programming step 8		

5.2.2 Power supply



5.2.3 Line bridging at removed detector head

If a detector head is removed from a detector line, the control unit signal a fault, while the manual call point is still able to set off an alarm (support diode bases BS5839Pt1)




Achieved with

- special add-on line card «BML1000» (factory equipped)
- special resistor EOL «FCE1003-B» (included in panel accessories) and Z-diode
- special detector base (eg. DB1102A, part number 534851) equipped with Schottky diode (1N5819) in parallel to the monitoring jumper inside detector head

5.2.4 Manual call point detection

It is possible to differentiate whether a detector or a manual call point has initiated alarm on the detector line. In this case manual call points must be equipped with a z-diode 5.6V/1W.




Achieved with

- option 4 selected on programming step 3 or
- option 8 selected on programming step 15

Note: A z-diode in series with a resistor and a LED is not possible for *call point detection*.

5.2.5 Zone extension module



Connections for zone extension

→ see chapter 5 *Peripheral connections Mainboard*

Settings for detector lines

Pos	Ref	Function	Parameter	Remark
1 to 2	PU1... PU4	Detector line 9 to 12	ON = none current limited (<i>Cerberus</i>) OFF = current limited (<i>Synova</i>)	Factory set

5.2.6 Control line extension card

Summary

The optional control line extension card features 4 monitored control outputs (control line 3 - 6). The following devices can be connected to the control outputs:

- Alarm devices like horns or flashlights
- Remote fire control installations
- RT devices

Functionality


The control outputs of control lines 3 – 6 have basically the same features as the control outputs of control lines 1 and 2. For the control lines 3 - 6, attention should be paid to the following:

- It is defined in programming step 5 when and how the control outputs are activated. In addition, each control output (control line 3 – 6) has a control input (A – D). Input A is related with output 3 etc. An AND combination between the setting in programming step 5 and the control input is enabled with a Jumper, e.g. control output 3 shall only be activated in case of alarm 2 AND driver output of zone 4 is active.
- Only control line 6 can be activated in case of a RT fault (see programming step 5, option 14). If so, the Jumpers have to be set accordingly (see table below).
- A LED is assigned to each control output. If the LED flashes, the corresponding control output has either a line break or a short line.

Connection

- The board will be connected via the enclosed ribbon cable on the connector CN10 to the main board.
- For power supply, a separate line has to run from the power supply card (terminals on the right side of the card) to the control line extension card.
- If a control line is not used, it has to be terminated with an EOL (FCE1002; included in delivery).

The allocation of connection can be seen in the following board illustration.



Ref.	Control line	Setting / Function
PU1, PU2	6	Pos. top = if option 14 progr. step 5 is selected Pos. bottom = if option 1-13 in progr. step 5 is selected
PU3	5	OFF = zone-specific activation (control input used) ON = common activation (control input not used)
PU4	6	
PU5	4	
PU6	3	
DL1	3	LED flashing upon break or short
DL2	4	LED flashing upon break or short
DL3	5	LED flashing upon break or short
DL4	6	LED flashing upon break or short
CN1		Connector for flat cable to main board

(A) Special Application: Line 6 used as remote control of state RT-fault

- Function: Line is activated in normal operating state and inactive in state *system fault* and on *power off* (FC10)
- Only possible with line 6
- Program option 14 in programming step 5
- Set jumper PU1 and PU2 on FCA1003 to position *top*
- Connect load between 350...2500 Ohm (without EOL)

5.2.7 RT-blocking card

Summary


With the optional RT-blocking card, the remote transmission of alarms and faults can be temporary isolated via a switch. This switch is located on the card and, therefore, is only accessible when the unit is open.

Connection

- The RT-blocking card will be connected to the mainboard on the terminal screws for remote transmission.
- The power supply (+, –) is provided via a connection between the RT-blocking card and mainboard (terminals *CL22*).
- In order that the display of RT-Blocking is also visible on the PMI, a connection between the RT-blocking card (*OUTPUT RT*) and the mainboard (programmable control input *PROGRAM*) has to be enabled. In addition, option 4 in the programming step 16 has to be defined.

Functionality and settings

- The switch on the card has the same function as key 11 on the PMI (temporary disconnection of *RT-Alarm* and/or *RT-Fault*)
- While switch is snapped in, the yellow LED lit on the board as well LEDs for the RT-Blocking on the PMI (*RT-Fault* and *RT-Alarm* disabled)
- The switch on the RT-blocking card has higher priority than the RT-disabling function on the PMI.
- Jumpers are used for settings whether the output is used as NO or NC (see table). This setting depends on the connected RT device.



Ref	Setting / Function
PU1, PU2	RT-Alarm – ON: NC contact – OFF: NO contact
PU3, PU4	RT-Fault – ON: NC contact – OFF: NO contact

5.3 Event processing

5.3.1 Alarm

The processing of alarm events is programmable mainly to prevent the unnecessary turnout of fire department for minor incidents. It involves personnel in the alarming sequence and relies on the operating mode *manned*. The system has to be run in operating mode *manned* as long as the responsible personnel is present. Mode *manned* has to be de-activated if the responsible personnel leaves the building.

Programmable parameters

Zone type

- via timer *V1/V2* in mode *manned* ; for detectors
- *direct* ; for manual call point, sprinkler alarms, etc.
- *internal* ; for non-fire-events, e.g. technical alarm


Timer for detector zones in mode *manned*

- range of *V1* 0.5 ... 4min; time to acknowledge the system before *RT-Alarm* is initiated
- range of *V2* 2 ... 10min; time to investigate the fire incident before *RT-Alarm* is initiated

5.3.2 Fault

The timer *V1* is also valid for *RT-Fault*. If the reported Fault is acknowledged before *V1* has expired then the contact *RT-Fault* will not be triggered.

5.3.3 Processing diagram



If all zones are set to zone type *direct* or *internal* then mode *manned* cannot be activated.

6 Operation and indicator elements, mode of operation (PMI)

6.1 Operating panel

6.1.1 General

The system operating panel is also called **Person Machine Interface** - PMI.

Overview operating functions

Related to Alarm	Related to disable system parts	Related to system test
<ul style="list-style-type: none"> • Acknowledge • Reset • Resound • Evacuation • Cancel alarm delay • Mode manned / unmanned 	<ul style="list-style-type: none"> • Disable / Enable zones 1 to xx • Disable / Enable alarm horn • Disable / Enable fire controls • Disable / Enable remote alarm • Disable / Enable remote fault 	<ul style="list-style-type: none"> • Mode <i>detector test</i> / Cancel • Mode <i>walk test</i> / Cancel • Test alarm horn for 30s • Simulation of <i>zone alarm</i> • Simulation of <i>zone fault</i> • Lamp test • Service function


Operating access

Level 1	Operating functions always possible
Level 2	Operating functions accessible via access code or key switch The default access code is 4233 <ul style="list-style-type: none"> • set individual access code, preferably 6 digits • disable access code if a key switch is used
Level 3	For user programming only, with additional access code

Inscription stripes


- Label the individual zone texts in the *Word* template (available via hotline).
- Each zone LED must have a clear individual zone text, which indicates the geographical location of the corresponding detectors and / or manual call points.
- Inserting inscription stripes

6.1.2 Indicators




LED	Labeling	LED	State active
1	System ON	on	if system is in operation (micro computer working)
2	Mode manned	on	if system is in operating mode <i>manned</i> – function suspended if all zones are set to <i>direct</i> or <i>internal</i> , – → see chapter <i>processing diagram</i>
3 and 4	ALARM	on slow fast	if system is on <i>Alarm</i> either flashing alternating while <i>V1/V2</i> are running (programmable step 4) or flashing synchronous on <i>unacknowledged</i> (programmable step 4)
5	Remote transmission	on	if contact <i>RT-Alarm</i> is <i>active</i> – if programmed also if contact <i>RT-Fault</i> is active
6	Operating access	on	if operating access is provided – timeout 3min after last key operation
7	System part disabled	on	if any system part is disabled or a zone is in mode <i>detector test</i>
8	Detector test	slow	if any zone is in mode <i>detector test</i>
9	Fault	fast	if any system part is on <i>Fault</i> – buzzer with pulsating sound
10	Earth fault	fast	if any system part has short circuit to earth
11	Power fault	fast slow	if battery is disconnected or low if mains supply voltage is missing or too low (after delay has expired)
12	System fault	on	if micro-computer has failed (system not working)
13	Alarm horn disabled / fault	on fast slow	if horn control lines are disabled if horn control line has a <i>break</i> or <i>short</i> if horn control lines are in mode <i>walk-test</i>
14	Controls disabled	on fast	if zone control outputs are disabled if control line programmed as fire control has a <i>break</i> or <i>short</i> (step 5, option 12, 13)
15	RT-Fault disabled / fault	on fast	if contact <i>RT-Fault</i> is disabled • if programmable control input with option 1 is active (Fault remote transmission device) • control input Fault RT is active • if control line programmed as fire control has a <i>break</i> or <i>short</i> (step 5, option 14)
17 (2/4) 23 (8/12)	RT-Alarm disabled	on fast	if contact <i>RT-ALARM</i> is disabled if control line programmed as <i>RT-Alarm</i> has a <i>break</i> or <i>short</i> (step 5, option 11)
16	Evacuation	on	if mode <i>Evacuation</i> is in process – during <i>Evacuation</i> , sounder control lines and buzzer are active – only usable if jumper on mainboard is set to enable

6.1.3 Operating keys



Nr	Labelling	Access	Function
1	Manned Unmanned	Level 2	to activate or de-activate mode <i>manned</i> (blocked in state <i>Alarm</i>) – function suspended if all zones are set to <i>direct</i> or <i>internal</i> , → see chapter processing diagram
2	Acknowledge	Level 1 or level 2	<ul style="list-style-type: none"> to acknowledge <i>Alarms</i> and <i>Faults</i> to silence buzzer and horn control lines to resound, 2nd activation starts horns again to stop horn test before running time (30s) is expired to de-activate mode <i>Evacuation</i>
3	Reset	Level 2	to reset <i>Alarm</i> (and also <i>Fault</i> , if programmed)
4...7	1 / 2 / 3 / 4	--	<ul style="list-style-type: none"> to provide operating access Level 2 (also possible with optional key switch) – enter password also used for other purposes
8	Cancel alarm delay	Level 1	to cancel alarm delay while timers V1/V2 are running in status <i>Alarm</i> – sets timers V1/V2 to zero
9	Lamp test Sounder test	Level 1 Level 2	<ul style="list-style-type: none"> to initiate lamp test if key is pressed for 1s – sets all LED and buzzer to state <i>active</i> for 5s to initiate horn test if key is pressed for >5s or hold numeric key 3 followed by pressing key 9 – activates horn control lines for 30s (stop, either with key <i>Acknowledge</i> or renewed pressing of key 9) – function is suppressed on <i>Alarm</i>
10	Disable Enable (Sounder controls)	Level 2	to temporarily disable the horn control lines and/or the fire controls – 1st key actuation disable horn control lines – 2nd key actuation disable controls – 3rd key actuation disable both – 4th key actuation enable both
11	Disable Enable (Remote transmission)	Level 2	to temporary disable the contacts <i>RT-Alarm</i> and/or <i>RT-Fault</i> – 1st key actuation disable RT-Fault – 2nd key actuation disable RT-Alarm – 3rd key actuation disable both – 4th key actuation enable both
12	Evacuation (can also be disabled)	Level 2	<ul style="list-style-type: none"> to activate mode <i>Evacuation</i> (horn control lines and buzzer) – only usable if jumper on mainboard is set to enable to de-activate mode <i>Evacuation</i> (also possible via key <i>Acknowledge</i>) – function also possible on <i>Alarm</i> (override)

6.1.4 Zone indicators and keys



Possible operating states zone	LED zone red	LED zone yellow
Alarm unacknowledged	fast	--
1st Alarm acknowledged	slow	--
Sub sequent alarm acknowledged (Alarm active)	on	--
Fault line break or line short	--	fast
Zone disabled	-- 1)	on
Zone in mode <i>detector Test</i>	--	slow
Zone in mode <i>detector Test</i> with temporary alarm activation ($\leq 10s$)	on	slow

1) state *disabled* does not apply for *line short alarms* (option 2 step 10) if option 4 step 15 is programmed

Possible action with key zone	Function	Result / subsequent function
1st activation	zone is disabled	Detector line set to 0V zone LED yellow = on
2nd activation	zone is set to mode <i>detector test</i> , allows to test each detector via test alarm on site	zone LED yellow = slow test-alarm activated: <ul style="list-style-type: none"> detector alarm indicator on zone LED red = on automatic <i>Reset</i> of test alarm after 10s
2nd activation and additionally $\leq 2s$ activation of numeric key 4	zone is set to mode detector test and additionally mode walk test is active	Same as above but additionally <ul style="list-style-type: none"> sounder control lines are activated for 3s with each test-alarm
3rd activation	to enable zone	detector line in normal operation

Auxiliary functions with key 'zone'	Function	Result / subsequent function
Hold numeric key 1 followed by pressing key zone	set zone to Alarm (Alarm simulation)	<ul style="list-style-type: none"> Alarm is initiated according to the setting of zone parameter normal Alarm processing
Hold numeric key 2 followed by pressing key zone	to set zone to Fault (Fault simulation)	<ul style="list-style-type: none"> Fault is initiated normal Fault processing Except: <ul style="list-style-type: none"> simulated zone Fault must be Reset

6.2 Display module

6.2.1 General

Optional display module that can be added on request in order to provide the functions listed below.

Functions and displayed information

Alarm counter	Counts up to 9999 alarms – spontaneous display – selectable RT-alarms only or RT-alarms and zone-alarms – internal alarms and test alarms are not counted
Expiry time V1/V2 (min/s)	Displays alarm delay – spontaneous display on alarm – shows the countdown of the time delays V1/V2
Clock	Displays actual system time – spontaneous display, possibly alternating with alarm counter – mainly used to switch automatically from mode manned to unmanned – also used for event memory
Event memory	History for register events with date and time – available upon polling – registers alarms, related events and other states – non-volatile memory that stores up to 320 events
Programming steps	For commissioning – displays the currently selected programming step
Service information	The display module displays the following information – last change of configuration (time and check sum) – last test alarm (time and zone) – version of firmware

Note:

The functions alarm counter, clock and event memory can be individually disabled if not required (see programming step 22)

Display mode

Battery operation and locked access	.	flashing dot (power save mode)
Counted RT alarms	0 2 5 7	--
Counted zone alarms	0 . 1 . 3 . 4	flashing dots
Date and time (h/min)	1 4 . 3 8	flashing dot except for the year indication
Time not set or not correct	8 8 . 8 8	all digits flash

6.2.2 Poll event memory

System must be on operating access level 2 and in state non-alarm

Polling	Input	Display	Remark
Newest event	hold key <i>Acknowledge</i> then enter code 1122	E.001.	always lowest event number
Year of event	press numeric <i>key 1</i>	2003	
Date of event	press numeric <i>key 2</i>	05.11.	
Hour and minute of event	press numeric <i>key 3</i>	15.37	
Next event (one event number upwards)	press key <i>Reset</i>	E.002.	2nd , 3rd, lowest event number etc.
Back to the newest event	press numeric <i>key 4</i>	E.001.	back to lowest event number
Exit	press key <i>Acknowledge</i>		at any step possible
Abort			on alarm and 1min after last key operation

The type of event is always shown by the corresponding indicator at the PMI according to table below.

Indicator PMI	Type of event	Remark
Red zone LED	<i>Alarm</i> corresponding zone	includes also simulated alarms, but no test alarms
LED 5	<i>RT-Alarm</i>	events with zone alarm and remote alarm simultaneously are registered as 2 events
LED 7	System part disabled	
LED 9	<i>Fault</i>	includes all types of fault events also simulated zone faults
LED 16	<i>Evacuation</i>	

6.2.3 Set clock

Set date and time

1. Give operating access on level 2
 - the system may not display any alarm or fault
2. Hold key *reset*, key in 4233 and confirm by pressing key *acknowledge*
 - LED *manned* and *operating access flash alternately*
3. Set year with the numeric keys 1 and 2
 - confirm setting with zone key 1 before proceeding to next option (month, day, etc.) by pressing key *reset* (backward by pressing zone key 1 and key *acknowledge*)
4. To end input sequence, press numeric key 4
 - timeout 3min after last entry
 - automatic stop after alarm or fault

Option	Selection	Setting digit 3 and 4	Display				
			digit 1	digit 2	dot	digit 3	digit 4
1	Year (03 to 99)	<ul style="list-style-type: none"> ● with numeric key 1 = up ● with numeric key 2 = down 	1	---	.	X	X
2	Month (01 to 12)		2			X	X
3	Day (01 to 31)		3			X	X
4	Hour (00 to 23)		4			X	X
5	Minute (00 to 59)		5			X	X
6	Adjustment +/- 20sec per day	key 1 to set clock 1-20sec faster key 2 to set clock 1-20sec slower	6	- (-) = (+)		x	x

It is only possible to go to the next option if the current entry is completed and accepted; otherwise, the buzzer will sound.

6.2.4 Poll service informations

The following information can be displayed on the display module:

- last change of configuration (date/time and check sum)
- last test alarm (date/time and zone number)
- version of firmware

Requirement

Queries about service information are only possible if there is no alarm and operating access on level 2 is given.

Procedure

1. Hold key *acknowledge* then, enter the password for the corresponding service information by using the numeric keys.
2. The requested query can be selected with the corresponding numeric keys.
3. To end the query, press key *acknowledge*. The request will be automatically stopped if an alarm occurs or if there is no further entry for more than a minute.

Query about the last change of configuration

Entry	Meaning	Display (example)
Hold key <i>acknowledge</i> and enter 11114444	password	P R O G
1	year (yyyy)	2 0 0 3
2	date (dd.mm.)	2 1.0 5.
3	time (hh.mm)	1 5.3 7
4	check sum user function	8.2.3.6.

Query about the last test alarm

Entry	Meaning	Display (example)
Hold key <i>acknowledge</i> and enter 33331111	password	T E S T
1	year (yyyy)	2 0 0 3
2	date (dd.mm.)	2 1.0 5.
3	time (hh.mm)	1 5.3 7
4	zone	0 8

Request about the firmware

Entry	Meaning	Display (example)
Hold key <i>acknowledge</i> and enter 2211	password entry firmware version is displayed	V _ 5.1

6.2.5 Delete alarm counter and event memory

Common command to delete both alarm counter and event memory.

1. Start	hold key <i>acknowledge</i> and key in code 3, 3, 2, 2, 1, 4, 4, 3 by using numeric keys	D E L	static
2. Approve	hold key <i>reset</i> and key in code 3, 4, 4, 1, 3, 3, 2, 1 by using numeric keys	. D E L .	flash simultaneously
3. Delete	press numeric key 2	. D E L .	static
4. Confirm	press simultaneously all numeric keys	0 0 0 0	flash for 15s
5. End	press key <i>acknowledge</i>	possible at any time	
Automatic stop		when <i>alarm</i> or 15s after last entry	

7 Commissioning

7.1 Procedure

Work to be done before commissioning

- installation of detector lines must be completed
- the connection of all detector bases and manual call points must be tested
- control unit must be mounted
- inscription stripes must be labeled and inserted
- all accessories must be available on site
- mains supply voltage must be available
- list of all field devices with clear geographical location must be available

Check electronic hardware

- check position of all jumpers and DIP switches
- connect detection lines or terminate with EOL
- connect horn control lines or terminate with EOL
- check whether the EOL is connected at the last detector, manual call point or horn of each line
- remove mains fuse inside the control unit



DANGER

External voltage

- connect mains supply line according to the local mains voltage
 - check mains fuse and earth connection
- place battery (but do not connect)
- insert mains fuse inside the control unit
- connect battery

Commissioning

- check the correct functioning of the system
- remove possible faults
- set the individual user functions as required and fill out log sheet
- initiate lamp test and check all LED
- test each operating key for correct functioning
- test all detectors, manual call points, horn control lines and remote transmission facility, see chapter *Testing peripheral devices*

The commissioning work is completed if

- the alarm processing of each zone is individually tested
- all detectors, manual call points, horn control lines and remote transmission facility have been tested and function correct
- the log sheet of user functions is completely filled out
- the system is set to normal operation and all system parts are enabled
- no fault message is reported
- the buzzer is enabled (jumper on mainboard)
- temporary operating access is removed (jumper on mainboard)




The system can now be handed over the customer

7.2 Testing peripheral devices

Procedure


Testing smoke detectors with DZ1193 or RE6

1. Set zone to mode *detector test*
2. Place testing unit on detector head
3. Wait until LED at detector head is on
4. Remove testing unit
 - automatic Reset of test alarm after 10s
5. Set zone to mode *normal operation*




Testing heat detectors RE6T

1. Set zone to mode *detector test*
2. Place testing unit on detector head and turn on heater
3. Wait until LED at detector head is on
4. Remove testing unit
 - automatic Reset of test alarm after 10s
5. Set zone to mode *normal operation*



Testing manual call points

1. Set zone to mode *detector test*
2. Depending on type of call point, insert test key or open cover to activate
3. Wait until LED is on
4. Remove test key or close door
 - automatic Reset of test alarm after 10s
5. Set zone to mode *normal operation*



Testing horn control lines

- Initiate *horn test* with key at the control unit
- Check whether the sound intensity is correct

Testing fire controls


- Make sure that the activation causes no damage to any building equipment
- Activate each fire control by initiating a real alarm and check whether the fire control functions are correct



8 Configuration

8.1 Programming user functions

In order to fulfill the local requirements, the programmable user functions may be adjusted by the single programming steps.



Procedure to enter programming mode

1. Set system to state non-alarm and provide operating access level 2 (see Operating access, page 20)
2. Hold key (3) and press numeric keys (7) 1, 4, 2, 4, 2, 3, 2, 1 one after the other
 - Continuous top-down flash up of LED block (1); indicates mode *programming*

Procedure to exit programming mode

1. Press numeric keys (7) 1 and 4 simultaneously
 - automatic timeout if no further key is pressed for more than 4min; LED block (1) stops flashing

Poll checksum (without display module)

In order to find out whether the user functions have been changed since the last visit of the service engineer.

1. Set system to mode *programming* (LED 1 = on)
2. Press numeric keys (7) 2 and 3 simultaneously
3. Read out LED sequence (4) within 10s (only possible once within programming sequence)
 - LED 1 and 8 are flashing slowly; indicating state *checksum*
4. write sequence of LED 2 to 7 into the checksum list

Note: Control unit with an equipped display module
→ see under *poll service information*

Set user functions to factory default settings

The user functions of all programming steps can be set to factory default values with one operation.

1. Disconnect mains and battery
2. Press and hold numeric keys (7) 1, 2, 3, 4 simultaneously followed by reconnecting mains
 - LED block (1) starts flashing
3. Release numeric keys (7)
4. Press numeric keys (7) 1, 2, 3, 4 simultaneously again
 - LED block (1) stops flashing and double beep of buzzer occurs
 - System is now set to default
5. Reconnect battery

Note: For factory default settings
→ see under *Log sheet for programmed user functions*

Set user functions to pre-settings 1 - 8


Note: The *selectable pre-settings* will be implemented with a later software release.

The user functions of all programming steps can be set to a selectable pre-setting with one operation.

1. Disconnect mains and battery
2. Press and hold numeric keys (7) 1, 2, 3, 4 simultaneously followed by reconnecting mains
 - LED block (1) starts flashing
3. Release numeric keys (7)
4. Select your pre-setting with key (3) upwards and key (2) downwards
5. The selected pre-setting is **either** indicated at LED block (4) LED 1 – 8, **or** at the optional display module (8)
6. Press numeric keys (7) 1, 2, 3, 4 simultaneously again
 - LED block (1) stops flashing and double beep of buzzer occurs
 - System is now set to the selected pre-setting
7. Reconnect battery

Note: For pre-settings 1 - 8
→ see details under *Log sheet for programmed user functions*

8.2 Programming steps



The selected programming steps are either indicated

- by the LED block (4), or
 - for programming steps 1 to 8 the corresponding LED is lit,
 - for programming steps 9 to 16 the corresponding LED is flashing
- by the optional display module (8)

The setting of an option can be selected with the zone keys (6) and is indicated with the corresponding red and yellow zone LED (5).

Select a programming step

- press key (3) to move upwards
- press key (2) to move downwards

Basic programming steps

LED	STEP	Define function
on	1	Timer V1
	2	Timer V2
	3	Processing of zone <i>Alarm</i> (zone type)
	4	LED activation mode <ul style="list-style-type: none"> • LED <i>Remote transmission</i> • LED <i>Alarm</i> • LED <i>System part disabled</i> on mode <i>manned</i>
	5	Activation mode of (horn) control lines 1 - 6
	6	Measures against false alarms <ul style="list-style-type: none"> • alarm verification • zone disabled in mode <i>manned</i>
	7	Control lines on <i>Alarm</i>
	8	Special zone parameters <ul style="list-style-type: none"> • behavior on immediate <i>Alarm</i> after <i>Reset</i> • function of zone control outputs
flashing	9	Suspend zone state self-hold on <i>Alarm</i> (technical <i>Alarms</i>)
	10	Detector line evaluation on <i>line short</i> or <i>line break</i>
	11	Cross-zoning
	12	Access code (password) <ul style="list-style-type: none"> • operating access • operating access for <i>acknowledge</i>
	13	Special PMI parameters <ul style="list-style-type: none"> • reminder beep on <i>fault</i> and <i>system part disabled</i> • <i>Fault</i> messages to be <i>Reset</i> • Suppress <i>battery fault</i>
	14	Delay on mains failure
	15	Special parameters <ul style="list-style-type: none"> • external <i>Acknowledge</i> and <i>Reset</i> • zones with special disabling procedure • <i>Remote transmission</i> on operating access • all zones with option 1 in step 3 react like option 4
	16	Programmable control input




Do not assign functions *cross zoning* (step 11) and *alarm verification* (step 6) simultaneously to the same zone!

Display programming steps

Step	Define function
22	indicating mode display <ul style="list-style-type: none"> • Function display mode • Function alarm counter
23	switching mode <i>manned/unmanned</i>
24	display switching time
25	switching time summer/winter time
26	switching time <i>manned/unmanned</i> <ul style="list-style-type: none"> • Time 1 • Time 2

8.3 Programmable functions



Procedure

1. Select the desired step with key (2) or (3)
2. Press the zone keys (6) as many times until the desired option is indicated with the corresponding zone LED (5) according to the following tables.

8.3.1 Step 1, timer V1

Option	Setting	Key	LED zone 1		LED zone 2	
			red	yellow	red	yellow
Function: Timer V1 on alarm or fault in mode manned						
1	0.5min	zone 1	off			
2	1min		on			
3	2min			on		
4	3min	zone 2			on	
5	4min					on

8.3.2 Step 2, timer V2

Option	Setting	Key	LED zone 1		LED zone 2	
			red	yellow	red	yellow
Function: Timer V2 on alarm in mode manned						
1	2min	zone 1	off			
2	3min		on			
3	4min			on		
4	5min	zone 2			on	
5	6min					on
			LED zone 3		LED zone 4	
6	7min	zone 3	on			
7	8min			on		
8	9min	zone 4			on	
9	10min					on

8.3.3 Step 3, zone processing on alarm

Option	Setting	Key	LED zone 1 - x	
			Red	yellow
Function: Zone alarm processing (zone type)				
1	via timer V1/V2	Zone 1 - x	off	
2	<i>direct</i> (timer bypassed) 1)		on	
3	<i>internal</i> 1) - RT and timer V1/V2 not initiated - Horn activated (unless disengaged in step 7)			on
4	via timer V1/V2, but call points always initiate <i>Alarm 2</i> (direct) → see also chapter 5 manual, manual call point detection		on	on

1) If all zones are set to *direct* or *internal*, the function manned/unmanned is disabled.

8.3.4 Step 4, LED activation mode

Option	Setting	Key	LED zone 1		LED zone 2	
			Red	yellow	Red	yellow
Function: Activation of LED remote transmission						
1	on <i>RT-Alarm</i> only	zone 1	off			
2	on <i>RT-Alarm</i> and <i>RT-Fault</i>		on			
Function: Flashing mode of the two LED Alarm						
3	alternating while <i>V1/V2</i> run	zone 1		off		
4	simultaneously on <i>unacknowledged</i> alarms			on		
Function: LED system part disabled on mode manned						
5	off in mode <i>manned</i>	zone 2			off	
6	on in mode <i>manned</i>				on	

8.3.5 Step 5, activation mode of (horn) control lines

Option	Setting	Key	LED zone 1 – 6	
			Red	yellow
Function: Activation mode of (horn) control lines 1-6				
1	continuous on <i>Alarm 1</i> and 2	zone 1 = control line 1 zone 2 = control line 2 zone 3 = control line 3 zone 4 = control line 4 zone 5 = control line 5 zone 6 = control line 6	off	
2	continuous on <i>Alarm 1</i> pulsating on <i>Alarm 2</i>		on	
3	pulsating on <i>Alarm 1</i> continuous on <i>Alarm 2</i>		slow	
4	pulsating on <i>Alarm 1</i> and 2		fast	
5	continuous on <i>Alarm 1</i> not activated with <i>Alarm 2</i>	control lines 3 – 6 with 8/12 zone panel only and additional control card	on	on
6	pulsating on <i>Alarm 1</i> not activated with <i>Alarm 2</i>		slow	on
7	not activated with <i>Alarm 1</i> continuous on <i>Alarm 2</i>		on	slow
8	not activated with <i>Alarm 1</i> pulsating on <i>Alarm 2</i>		slow	slow
9	continuous on <i>Alarm 1</i> and 2		on	fast
10	not activated with <i>Alarm 1</i> continuous on <i>Alarm 2</i>		fast	on
11	continuous on <i>RT-Alarm</i> – same facility as <i>RT-Alarm</i>			on
12	continuous on <i>Alarm 1</i> and 2 – same facility as driver output (fire controls)			slow
13	continuous on <i>Alarm 2</i> – same facility as driver output (fire controls)			fast
14	continuous on <i>RT-Fault</i> – same facility as <i>RT-Fault</i> (until inactive) – possible with control line 6 only		fast	fast

Option 1 to 8 active until *Acknowledge*

Option 9 to 13 active until *Reset*

8.3.6 Step 6, measures against false alarms

Option	Setting	Key	LED zone 1 - x	
			Red	yellow
Function: Zone with alarm verification				
1	no alarm verification	zone 1 - x	off	
2	Alarm only if second Alarm within 60sec 1st alarm = automatic Reset with short flash up of zone LED		on	
Function: Zone disabled in mode manned				
3	not disabled	zone 1 - x	off	
4	disabled as long as mode <i>manned</i> is active			on

Note: These measures are only justified on severe environmental conditions.

8.3.7 Step 7, control lines on alarm

Option	Setting	Key	LED zone 1 - x	
			Red	yellow
Function: Zone with not activated control lines on Alarm				
1	both control lines <i>activated</i>	zone 1 - x	off	
2	both control lines <i>not activated</i>		on	on
3	control line 1 <i>not activated</i>		on	
4	control line 2 <i>not activated</i>			on

8.3.8 Step 8, special zone parameters

Option	Setting	Key	LED zone 1 - x	
			Red	yellow
Function: Behavior on Alarm immediately after Reset				
1	renewed <i>Alarm</i>	zone 1 - x	off	
2	<i>alarm</i> <15s after <i>Reset</i> initiates <i>line Fault</i>		on	
Function: Driver output per zone				
3	active if zone is on <i>Alarm</i> – remains until <i>Reset</i>	zone 1 - x	off	
4	active if zone is on <i>Alarm</i> , <i>Fault</i> , <i>Disabled</i> or <i>Test</i> – remains until <i>Reset</i> or state <i>inactive</i>			on

8.3.9 Step 9, zone self hold state

Option	Setting	Key	LED zone 1 - x	
			Red	yellow
Function: Suspend zone state self-hold on Alarm (technical Alarms)				
1	with self-hold	zone 1 - x	off	
2	without self-hold but with buzzer on <i>Alarm</i>		on	
3	without self-hold and without buzzer on <i>Alarm</i>			on

8.3.10 Step 10, detector line short or break

Option	Setting	Key	LED zone 1 - x	
			Red	yellow
Function: Zone state self-hold on Alarm				
1	state <i>line short</i> / <i>break</i> = <i>Fault</i>	zone 1 - x	off	
2	state <i>line short</i> = <i>Alarm 2</i> state <i>line break</i> = <i>Fault</i>		on	
3	state <i>line break</i> = <i>Alarm 2</i> state <i>line short</i> = <i>Fault</i>			on
4	state <i>line short</i> = <i>Alarm 1</i> state <i>line break</i> = <i>Fault</i>		on	on

8.3.11 Step 11, cross zoning

Option	Setting	Key	LED zone 1 - x	
			Red	yellow
Function: Zone pair in cross-zoning on alarm				
1	no cross-zoning	zone A+B	off	
2	cross-zoning type 1 – zone A or B = no Alarm; <i>reset</i> after 6min – zone A + B = <i>Alarm 1</i>		on	
3	cross-zoning type 2 – zone A or B = <i>Alarm 1</i> – zone A + B = <i>Alarm 2</i>			on
4	cross-zoning type 3 – zone A or B = <i>Alarm 0</i> (internal alarm) – zone A + B = <i>Alarm 1</i>	–	on	on
Remark: Only possible with defined zone pairs 1+2, 3+4 up to 11+12. Named in table with A and B. Procedure: 1. Hold zone key A then press zone key B – Type 1 is now selected (red LED on both zones are lit) 2. Hold zone key A then press zone key B – Type 2 is now selected (yellow LED on both zones are lit) 3. Hold zone key A then press zone key B – No cross zoning selected (red and yellow LED on both zones are lit) 4. Hold zone key A then press zone key B – No cross zoning selected (no zone LED lit)				

8.3.12 Step 12, access code

Option	Setting	Key	LED zone 1		LED zone 2	
			Red	Yellow	Red	yellow
Function: Password to provide operating access (level 2)						
1	basic access code (4, 2, 3, 3) defined	zone 1	off			
2	individual access code Procedure: 1. enter code by pressing key 1 to 4 in the desired sequence then press key zone 1 – red LED flashing 2. repeat same input sequence and press key zone 1 again (confirm code) – red LED now turns to on – yellow LED flashing = code not accepted (repeat procedure)		on			
3	no access code required (access via key switch)	zone 1 + 2	on	on		
Function: Operating access to key Acknowledge						
4	<i>Acknowledge</i> always accessible	zone 2	off			
5	<i>Acknowledge</i> only accessible via access code (Access level 2)				on	

Note: Access is permanently provided if jumper PU9 resp. PU16 is set on mainboard (override of access code)

8.3.13 Step 13, special PMI parameters

Option	Setting	Key	LED zone 1		LED zone 2	
			Red	Yellow	Red	yellow
Function: Reminder beep (Buzzer) upon Fault and System part Disabled						
1	no reminder beep	zone 1	off			
2	reminder beep activated – beep of 1s every 4min		on			
Function: Fault messages to be Reset						
3	Acknowledged <i>faults</i> must not be reset	zone 2			off	
4	<i>Faults</i> must be acknowledged and after being restored reset				on	
Function: Suppress battery fault						
5	not suppressed	zone 2 + num. 4			off	
6	suppressed				on	

8.3.14 Step 14, delay mains failure

Option	Setting	Key	LED zone 1		LED zone 2	
			red	yellow	red	yellow
Function: Delay of Fault initiation due to mains failure						
1	delay = 0s	zone 1	off			
2	delay = 3min		on			
3	delay = 10min			on		
4	delay = 30min	zone 2			on	
5	delay = 3h					on

8.3.15 Step 15, special parameters

Option	Setting	Key	LED zone 1		LED zone 2	
			red	yellow	red	yellow
Function: Acknowledge and Reset from external blocked during RT alarm active						
1	not blocked	zone 1	off			
2	blocked		on			
Function: Zones set to option 2 in step 10 with special disabling procedure						
3	not activated	zone 1	off			
4	alarm on <i>line short</i> even if zone is disabled			on		
Function: RT-Fault and RT-Alarm disabled if state operating access is provided						
5	not disabled	zone 2			off	
6	disabled				on	
Function: All zones with option 1 in step 3 react like option 4						
7	not activated	zone 2			off	
8	activated					on

8.3.16 Step 16, programmable control input

Option	Setting	Key	LED zone 1		LED zone 2	
			red	yellow	red	yellow
Function: Programmable control input						
1	initiate <i>Fault</i> remote transmission device	zone 1	off			
2	provide <i>operating access</i>		on			
3	initiate state <i>Evacuation 1)</i>			on		
4	disable <i>RT-Alarm + RT-Fault</i>	zone 2			on	
5	de-activate mode <i>manned</i> (pulse)					on
6	initiate mode <i>manned</i>			on		on

Options 1 to 4 and 6: active as long as positive potential is applied
 1) *Evacuation* will be activated even if jumper *evacuation* is set to off

8.3.17 Step 22, indicating mode display

Option	Setting	Key	LED zone 1		LED zone 2	
			red	yellow	red	yellow
Function display mode						
1	clock, alarm counter and event memory	zone 1	off			
2	alarm counter only (clock turned off)		on			
3	clock and event memory			on		
4	clock and alarm counter		on	on		
Function alarm counter						
5	RT-alarms only	zone 2	off			
6	zone alarms only			on		
7	RT-alarms and zone alarms alternating			on		

8.3.18 Step 23, switching mode manned/unmanned

Option	Setting	Key	LED zone 1		LED zone 2	
			red	yellow	red	yellow
Function: Automatic switching mode from manned to unmanned						
1	manual switching from <i>manned</i> to <i>unmanned</i>	zone 1	off			
2	automatic switching from <i>manned</i> to <i>unmanned</i>			on		

8.3.19 Step 24, display switching time

Option	Setting	Key	LED zone 1		LED zone 2	
			Red	yellow	red	yellow
Function: Display of switching time after manual switch from manned to unmanned						
1	switching time displayed	zone 1	off			
2	switching time not displayed			on		

8.3.20 Step 25, switching mode summer/winter time

Option	Setting	Key	LED zone 1		LED zone 2	
			red	yellow	red	yellow
Function: Switching summer/winter time and vice versa automatically						
1	automatic switching from summer to winter time	zone 1	off			
2	manual switch from summer to winter time			on		

8.3.21 Step 26, switching time manned/unmanned

Option	Setting	Key	LED zone 1		LED display				
			red	yellow	figure 1	figure 2	point	figure 3	figure 4
Function switching time 1 for automatic switching from manned to unmanned									
1	default setting	zone 1			1	8	.	0	0
2	individual setting – press key 2 to adjust the hours – press key 3 to adjust the minutes		on		x	x	.	x	x
Function switching time 2 for automatic switching from manned to unmanned									
3	default setting	zone 1			--	--	.	--	--
4	individual setting – press key 2 to adjust the hours – press key 3 to adjust the minutes		on	x	x	.	x	x	
Procedure									
1. Press key zone 1 until the red zone LED (switching time 1) or the yellow zone LED (switching time 2) is lit									
2. Press numeric key 2 to set the hours (start with hour 00:xx to 23:xx upwards)									
3. Press numeric key 3 to set the minutes (start with minute xx:00 to xx:59 upwards)									
– Display “-- -- . -- --” means on switching time set									

8.4 Log sheet for programmed user functions

Installation: Selected pre-setting:

Basic programming steps

Note: The selectable *pre-settings* will be implemented with a later software release.

Programming steps and functions		Set options (parameter)										Individual settings of a selected pre-setting
		Selectable pre-settings										
		Factory	1	2	3	4	5	6	7	8		
1	Timer V1	1									min :	
2	Timer V2	1									min :	
3	Processing of zone <i>Alarm</i> (zone type)	1									Option 1, zone: Option 2, zone: Option 3, zone: Option 4, zone:	
4	LED activation mode • LED <i>Remote transmission</i> • LED <i>Alarm</i> • LED <i>System part disabled</i> on mode <i>manned</i>	1 3 6									
5	Activation mode of (horn) control lines 1 – 6	1									Line 1, option: Line 2, option: Line 3, option: Line 4, option: Line 5, option: Line 6, option:	
6	Measures against false alarms • alarm verification • zone disabled in mode <i>manned</i>	1 3									active zone active zone	
7	Control lines on <i>Alarm</i>	1									Option 1, zone: Option 2, zone: Option 3, zone: Option 4, zone:	
8	Special zone parameters • behavior on immediate <i>Alarm</i> after <i>Reset</i> • function of zone control outputs	1 3									Option 1, zone: Option 2, zone: Option 3, zone: Option 4, zone:	
9	Suspend zone state self-hold on <i>Alarm</i> (technical <i>Alarms</i>)	1									Option 1, zone: Option 2, zone: Option 3, zone:	
10	Detector line evaluation on <i>line short</i> or <i>line break</i>	1									Option 1, zone: Option 2, zone: Option 3, zone: Option 4, zone:	
11	Cross-zoning	1									Option 1, zone: Option 2, zone: Option 3, zone:	
12	Access code (password) • operating access • operating access for <i>acknowledge</i>	1 4									
13	Special PMI parameters • reminder beep on <i>fault</i> and <i>system part disabled</i> • <i>Fault</i> messages to be <i>Reset</i> • suppress battery <i>fault</i>	1 3 5									
14	Delay on mains failure	3										
15	Special parameters • external <i>Acknowledge</i> and <i>Reset</i> • zones with special disabling procedure • <i>Remote transmission</i> on operating access • all zones with option 1 in step 3 react like option 4	1 3 5 7									
16	Programmable control input	1									

Display programming steps

Programming steps and functions		Set options (parameter)									Individual settings of a selected pre-setting
		Selectable pre-settings									
		Factory	1	2	3	4	5	6	7	8	
22	indicating mode display ● Function display mode ● Function alarm counter	1 5								
23	switching mode manned/unmanned	1								
24	display switching time	1								
25	switching time summer/winter time	1								
26	switching time manned/unmanned ● Time 1 ● Time 2	18:00 - :- -								

8.5 Checksum

Checksum to fill in when programming is completed

Without display module

Date of last changes	LED 2 on	LED 3 on	LED 4 on	LED 5 on	LED 6 on	LED 7 on	Remarks

With display module

Year	Date	Time	Checksum

9 Maintenance

9.1 General

The fire detection installation requires only little maintenance work. It has a high degree of self monitoring, such as

- detectors monitored on presence, lines on wire break and short circuit
- call points monitored on broken glass, lines on wire break and short circuit
- horn control lines monitored on wire break and short circuit
- battery monitored on presence and capacity
- permanent system checking by watchdog function
- programmed user functions are stored in FLASH-memory

9.2 Recommended system performance checks

We recommend the following schedule for the system performance checks. However, possible local national regulations have priority.

Alarm organization

Performance checks	Interval in years		
	1	2	5
• Check the functioning of delay times <i>V1</i> and <i>V2</i>	X		
• Verify switchover mode <i>manned</i> to <i>unmanned</i> and vice versa manually	X		
• Activate automatic detectors while system is set to mode <i>unmanned</i>	X		
• Activate automatic detectors while system is set to mode <i>manned</i>	X		
• Activate manual call points	X		
• Check activation of remote transmission equipment	X		

Alarm horn

Performance checks	Interval in years		
	1	2	5
• Activate alarm horn test and check all acoustic alarm devices	X		

Detector network

Performance checks	Interval in years		
	1	2	5
• Activate one detector within each line and verify zone assignment and parameters	X		
• Check all detectors and call points visually	X		
• Activate all detectors and manual call points		X	
• Check each detection line whether a short circuit or open line activates a <i>fault</i>			X
• Overhaul all automatic detectors at the factory – at latest after 5 years in clean environment, otherwise earlier			X

Refer also to the corresponding detector manuals

Fire control installations

Performance checks	Interval in years		
	1	2	5
• Check activation of each fire control relay	X		
• Check correctness of each shutdown operation	X		

Operating panel


Performance checks	Interval in years		
	1	2	5
Clean front panel with mild soap - do not use aggressive or abrasive solvents	X		
Activate lamp test	X		
Check correctness and readability of the inscription stripes	X		
Check key-click of each key	X		
Check access facility	X		

Inside control unit

Performance checks	Interval in years		
	1	2	5
Check earth connections	X		
Visual check of battery	X		
Remove dust	X		

10 Trouble shooting

10.1 Interpretation of fault LED flashing



Indicator		Cause / Action to be taken
LED 9	Fault flashing fast	There is a fault in the system <ul style="list-style-type: none"> ● check if there is another fault LED flashing, if not ● check if control input <i>Fault</i> is activated
LED 10	Earth fault flashing fast	Any part of the system has a leakage to earth <ul style="list-style-type: none"> ● Remove one external line (detector line etc.) after the other until the fault disappears, then repair the defective line ● if no external line has a leakage to earth replace mainboard
LED 11	Power fault flashing fast flashing slow	Battery is disconnected or low <ul style="list-style-type: none"> ● Replace battery Mains supply is missing (after delay has expired) <ul style="list-style-type: none"> ● Check internal fuse or external mains breaker
LED 12	System fault flashing fast	The microcomputer has failed (system not working) <ul style="list-style-type: none"> ● Switch power off and restart, if fault continues replace mainboard
LED 13	Alarm horn fault flashing fast	There is a fault in the monitored control lines (horn) <ul style="list-style-type: none"> ● Check lines for a short circuit or break or missing/defective EOL ● If control card FCA1003 is used, check LEDs DL1 - DL4 to define faulty line
LED 14	Fire controls fault flashing fast	There is a fault on a monitored control line (programmed in step 5 to option 12 or 13) <ul style="list-style-type: none"> ● Check line for a short circuit or break or missing/defective EOL
LED 15	RT-Fault flashing fast	Control input Fault RT is active, or if programmable control input with option 1 is active (Fault remote transmission device) <ul style="list-style-type: none"> ● Check remote transmission device There is a fault on a monitored control line (programmed in step 5 to option 14) <ul style="list-style-type: none"> ● Check line for a short circuit or break or missing/defective EOL
LED 23	RT-Alarm flashing fast	There is a fault on a monitored control line (programmed in step 5 to option 11) <ul style="list-style-type: none"> ● Check line for a short circuit or break or missing/defective EOL
LED zone x	Yellow zone LED flashing fast	There is a fault in zone number x <ul style="list-style-type: none"> ● Check whether any detector head is removed ● Check line for short circuit or break or missing/defective EOL
Display	Indicates 88.88	Clock not set (with new system start up or after power down) <ul style="list-style-type: none"> ● Set date and time

11 Components and spare parts

11.1 Components

Type	Part number	Description	Remarks
FC1008-A	A6E60500007	control unit 8 zones	
FC1008-B	A6E60500008	control unit 8 zones GB	
FC1008-C	A6E60500009	control unit 8 zones Nordic	
FC1012-A	A6E60500014	control unit 12 zones	
FC1012-B	A6E60500015	control unit 12 zones GB	
FC1012-C	A6E60500016	control unit 12 zones Nordic	

11.2 Accessories

Type	Part number	Description	Remarks
FCA1003	A6E60500022	control card	
FCA1002	A6E60500021	display unit	
FCA1005-D	A6E60500024	RT-Isolation card	
Z3B171	484383	fire control relay 1 contact 250VDC/10A	
FCA1007	A6E60500026	kit key switch	incl. mounting instruction
AX1212	484325	battery 12V/12Ah	can also be
AX1210	475570	battery 12V/15 - 18Ah	purchased locally

11.3 Spare parts

Power supply

Type	Part number	Description	Remarks
FCP1003	A6E60500053	Transformer 8/12 zones	
FCP1001	A6E60500051	Power supply card 8/12 zones	

Electronic cards

Type	Part number	Description	Remarks
FCM1008	A6E60500049	Mainboard 8 zone	
FCA1001	A6E60500020	Line extension card 4 zones	
FCA1007-B	A6E60500023	Line card GB	

EOL

Type	Part number	Description	Remarks
FCE1001	A6E60500031	EOL resistor 3k9 (dedector line)	(set of 10 pieces)
FCE1003-B	A6E60500033	EOL element GB	
FCE1002	A6E60500032	EOL element control line	

Cabinet cover

Type	Part number	Description	Remarks
FCH1008	A6E60500038	Cover with PMI 8 zone	
FCH1012	A6E60500043	Cover with PMI 12 zone	

12 Disposal and environmental protection

12.1 General

The customer is in charge of the disposal of Siemens fire detection systems. In case of any uncertainty relative to the disposal process, which might cause danger to people or to the environment, please consult the Technical Customer Service of Siemens Building Technologies AG.

The putting out of service and disposal of a system must be communicated to Siemens Building Technologies AG.

12.2 Disposal

**DANGER**

Prior to the disposal the system must be put out of service by the Technical Customer Service of Siemens Building Technologies AG. The system must be disconnected from the power supply – otherwise serious bodily injury or even danger to life could result!

Function units

The following modules should be particularly taken into consideration:

- Batteries
- Electronic modules (control units, all detectors)
- Switching cabinets

Disposal regulations

With regard to the disposal of the Siemens fire detection system, local and regional regulations and guidelines must be taken into account.

Siemens Building Technologies AG
Alte Landstr. 411
CH-8708 Männedorf
Tel. +41 1 - 922 6111
Fax +41 1 - 922 6450
www.sbt.siemens.com

© 2003 Copyright by
Siemens Building Technologies AG
Data and design subject to change without notice. Supply subject to
availability.