

# Instruction Manual

## Premier Elite Impaq Contact-W




### INTRODUCTION

- For wireless connectivity, detailed programming and system set-up instructions please refer to the compatible RICOCHET™ technology enabled *Premier Elite* wireless expander instructions.
- Featuring RICOCHET™ wireless technology the *Impaq Contact-W* is designed for professional security installations.
- When using the *Impaq Contact-W* on an Entry/Exit route, or a 24HR door, or where chime is required, the device attributes should be left at default "Always Awake".
- Please see the *Premier Elite 8XP-W/32XP-W* Installation Manual for details of how to change the device attributes.

### ASSEMBLY

For rear tamper - fix both the detector AND the rear tamper insert to the mounting surface. Activation of rear tamper will damage product.

#### Rear Tamper Insert




### Battery

Only replace with 3V Lithium CR123A.

#### Battery Safety

- Do not throw into a fire
- Do not heat
- Do not charge
- Do not short circuit
- Do not disassemble
- Replace only with same or equivalent type
- Always observe local regulations when disposing of a battery
- Detector will transmit low battery warning when battery needs replacing




## ADDITIONAL INPUTS 1 & 2

The *Impaq Contact-W* has 2 additional inputs. These may be used for any N/C device and utilise wireless signal transmission to the receiver. Typical examples for use are:-

- Any locally powered device with a N/C output e.g. Smoke detectors, Glass Break detectors, Movement Sensors, Flood detectors etc.
- Any non-powered N/C device, e.g. Additional magnetic contacts, fixed PA buttons etc.
- The in-built reed switch can be disabled.
- Configuration and programming options are detailed in the *Premier* wireless expander installation manual.
- Certain features and functions are control panel software dependent.

## MAGNET POSITIONING

Fig.1




Magnets can be installed either side of the unit.
Non-Ferrous Mounting Material maximum displacement
X = 15mm   Y = 10mm   Z+ = 20mm   Z- = 10mm
• Values depend on mounting material
• Reference points are from the centre of the device and the centre of the magnet

## LED STATUS INDICATION

**Only available in walktest mode**  
(See *Premier* wireless expander instructions)

<b>Flashing Green:</b>	With all contacts secure, will flash every 3 seconds.
<b>Red:</b>	Indicates either the reed switch or external contacts are active.



## STANDARDS

<b>Alarm Systems:</b>	EN50131-2-2, EN50131-5-3, EN50131-1, PD6662, Grade 2 Class II
<b>EMC:</b>	EN50130-4:1995 A1: A2 ETSI EN301 489-03 V1.4.1
<b>R&amp;TTE:</b>	ETSI EN300-220 (v2.1.1)
<b>Environmental:</b>	EN50130-5
<b>Frequency Band:</b>	868.0 - 868.6 MHz / 433.05 - 434.79 MHz • Please refer to product label
<b>Receiver:</b>	Category 1, Class 2
<b>Receiver LBT (Listen Before Talk)</b>	Yes
<b>Transmitter Duty Cycle</b>	868Mhz < 1%, 433Mhz < 10%
<b>Low Voltage Signal</b>	2.85V
<b>Operating Voltage</b>	3V
<b>Maximum current</b>	32mA
<b>Quiescent current</b>	60uA

## WARRANTY

2 year replacement warranty (excludes battery).

The *Impaq Contact-W* is designed to detect the opening of a door/window and activate an alarm control panel. As the *Impaq Contact-W* is not a complete alarm system, but only a part thereof, *Texecom* cannot accept responsibility or liability for any damages whatsoever based on a claim that the *Impaq Contact-W* failed to function correctly.

Due to our policy of continuous improvement *Texecom* reserves the right to change specification without prior notice. All specifications are made at 20°C (68°F).



Certificate Number: FM 35285

Made In England

HALMA GROUP COMPANY



*Impaq* and the wireless logo are trade marks of *Texecom* Ltd. © 2011

The *Impaq Contact-W* is protected by European Registered Design. No: 269188-0001  
C20110109 INS468-3