

2-Wire VTO2000A-2 User's Manual

V1.0.0

Table of Contents

Table of Contents	i
1 Product Overview	1
1.1 List of Models	1
1.2 Structure	1
1.2.1 Dimension	1
1.2.2 Front Panel	2
1.2.3 Rear Panel	3
1.3 System Networking	3
1.3.1 One-to-One Scene	3
1.3.2 Group Call Scene	4
2 Install VTO	5
2.1 Direct Installation	5
2.1.1 Screw	5
2.1.2 Dimension	5
2.1.3 Installation Step	6
2.2 Embedded in Wall	8
2.2.1 Screw	8
2.2.2 Dimension	9
2.2.3 Installation Step	9
2.3 Wiring	11
2.4 Electric Control Lock and Electromagnetic Lock	12
2.4.1 Electric Control Lock	12
2.4.2 Electromagnetic Lock	12
3 Installation Debugging	14
3.1 WEB Setup	14

3.2	General Config	15
4	Web Config.....	17
4.1	System Config	17
4.1.1	Local Config.....	17
4.1.2	LAN Config	18
4.1.3	Indoor Manager	18
4.1.4	Network Config	19
4.1.5	Video Set.....	20
4.1.6	User Manage.....	21
4.2	Info Search	22
4.2.1	Call History.....	22
4.2.2	Alarm Record	22
4.3	Status Statistics	23
4.3.1	VTH Status	23
4.4	Logout.....	23
5	Basic Function Introduction	24
5.1	Call Function	24
5.1.1	Call Manager Center.....	24
5.1.2	Call User.....	25
5.1.3	Group Call	25
5.2	Monitor.....	28
5.3	Unlock Function	28
5.4	Compensation of Light	29
5.5	Vandal Proof	29
5.6	Restore Backup	29
6	FAQ	30
	Appendix 1 Technical Specifications	31
	Appendix 2 Technical Specifications	32
	Appendix 2.1 Cable Specification.....	32
	Appendix 2.2 Power Extension Line Specification	32

Appendix 2.3 Embedded Box.....	32
Appendix 3 VTMS.....	33
Appendix 4 VTMS Client.....	35
Appendix 4.1 Config Network Address.....	35
Appendix 4.2 Create Organization	37

Important Safeguards and Warnings

Please read the following safeguards and warnings carefully before using the product in order to avoid damages and losses.

Note:

Do not expose the device to lampblack, steam or dust. Otherwise it may cause fire or electric shock.

Do not install the device at position exposed to sunlight or in high temperature. Temperature rise in device may cause fire.

Do not expose the device to humid environment. Otherwise it may cause fire.

The device must be installed on solid and flat surface in order to guarantee safety under load and earthquake. Otherwise, it may cause device to fall off or turnover.

Do not place the device on carpet or quilt.

Do not block air vent of the device or ventilation around the device. Otherwise, temperature in device will rise and may cause fire.

Do not place any object on the device.

Do not disassemble the device without professional instruction.

Warning:

Please use battery properly to avoid fire, explosion and other dangers.

Please replace used battery with battery of the same type.

Do not use power line other than the one specified. Please use it properly. Otherwise, it may cause fire or electric shock.

Special Announcement

This manual is for reference only.

All the designs and software here are subject to change without prior written notice.

All trademarks and registered trademarks are the properties of their respective owners.

If there is any uncertainty or controversy, please refer to the final explanation of us.

Please visit our website for more information.

1 Product Overview

1.1 List of Models

Model	Chassis Material	Color	Unlock via IC card	Button Type	Lock Control Module
VTO2000A-2	Metal	Silver	N/A	Mechanical key	Built-in

1.2 Structure

1.2.1 Dimension

Before you install the device, please make sure you know the dimension of device and select appropriate installation method. See Figure 1- 1.




Figure 1- 1

1.2.2 Front Panel




Figure 1- 2

No.	Port Name	Note
1	MIC	Audio input.
2	Camera	It monitors corresponding door region.
3	Compensation Light	Light compensation will automatically turn on during monitoring, calling, or connecting status if there is no enough light in environment.
4	Speaker	Audio output.
5	User Nameplate	Display username and other info.
6	Call Button	Call center or VTH.

1.2.3 Rear Panel




Figure 1- 3

No.	Component Name	Note
1	Camera Angle Adjustment	Adjust camera angle.
2	Vandal-proof Switch	When VTO if forced to leave wall, it will alarm and report to MGT center.
3	User Port	Connect to lock, door sensor feedback and unlock button.
4	Project Port	Reserved for project staff use.

1.3 System Networking

This chapter mainly introduces usage of digital VTO, please read the following content and install the device according to your actual condition.

1.3.1 One-to-One Scene

Visitor press Call button to call residence (as VTH) or Center. See Figure 1- 4.




Figure 1- 4

1.3.2 Group Call Scene

When visitor press Call button on VTO, multiple VTHs will ring at the same time. User can call, hang up, and unlock on any of these VTHs.

Note:

VTH has 1 master VTH and up to 3 extension VTHs.

See Figure 1- 5.




Figure 1- 5

2 Install VTO

2.1 Direct Installation

2.1.1 Screw

Before installing VTH, please check screws on accessory bag according to the following specifications and install by following this guide.





Component Name	Illustration	Quantity
M3×6 Hex slot pan head tail machine screws --- galvanizing white		4
M3×8 Cross recessed countersunk head tail machine screws --- galvanizing white		4
ST3×18 Cross recessed countersunk head tail tapping screws --- galvanizing white		4
White expansion tube \varnothing 6×30mm		4

Chart 2- 1

Note:

M3x6 or M3x8 either is OK.

2.1.2 Dimension

Before you install the device, please make sure you know the dimension of device and select appropriate installation method. See Figure 2- 1.




Figure 2- 1

2.1.3 Installation Step

- Step 1. Install metal bracket into the groove on wall. At spot 1 fasten screw (ST3×18 Cross recessed countersunk head tail tapping screws --- galvanizing white), and fix metal bracket on wall. See Figure 2- 2
- Step 2. Align the device on metal bracket according to screw hole. At spot 2 fasten screw (M3×8 Cross recessed countersunk head tail machine screws --- galvanizing white), and fix device on metal bracket. See Figure 2- 3.




Figure 2- 2




Figure 2- 3

2.2 Embedded in Wall

2.2.1 Screw

Before installing VTH, please check screws on accessory bag according to the following specifications and install by following this guide.



Component	Illustration	Quantity
M3×6 Hex slot pan head tail machine screws--- galvanizing white		4
M3×8 Cross recessed countersunk head tail machine screws --- galvanizing white		4

Chart 2- 2

Note:

M3x6 or M3x8 either is OK.

2.2.2 Dimension

Before you install the device, please make sure you know the dimension of device and select appropriate installation method. See Figure 2- 4.




Figure 2- 4

2.2.3 Installation Step

- Step 1. Dig a hole on wall, its dimension is 117*128*80(mm).See Figure 2- 5.
- Step 2. Embed metal bracket into wall until its four peaks lean against the wall. See Figure 2- 6.
- Step 3. Align the device on metal bracket according to screw hole. At 2 spots fasten screws (M3×8 Cross recessed countersunk head tail machine screws --- galvanizing white), and fix device on metal bracket. See Figure 2- 7.




Figure 2- 5




Figure 2- 6




Figure 2- 7

2.3 Wiring

See Figure 2- 8.




Figure 2- 8

No.	Component Name	Note
1	User Port	Power supply, connect to lock, door sensor and

		unlock button.
2	Project Port	Reserved for project staff use.

2.4 Electric Control Lock and Electromagnetic Lock

2.4.1 Electric Control Lock

When VTO connects to electric control lock, it means that the positive end of electronic control lock connects to NO of VTO (user port 10) while its negative end connects to COM of VTO (user port 12).

When VTO connects to unlock button, one end of unlock button connects to UNLOCK BUTTON of VTO (user port 7) while the other end connects to GND of VTO (user port 9). See Figure 2- 9.




Figure 2- 9

2.4.2 Electromagnetic Lock

When VTO connects to electromagnetic lock, it means that the positive end of electromagnetic lock connects to NC of VTO (user port 11) while its negative end connects to COM of VTO (user port 12).

When VTO connects to door sensor in electromagnetic lock, one end of door sensor connects to FEEDBACK of VTO (user port 8) while the other end connects to GND of VTO (user port 9). See Figure 2- 10.




Figure 2- 10

3 Installation Debugging

Warning:

- Before debugging, the staff shall be familiar with device's installation, wiring and usage.
- Before debugging, check wiring for short or open circuit.
- When staff find each circuit is normal, plug the device to power.
- After debugging, clear the site.

3.1 WEB Setup

If you first use VTO, you may need to operate according to the following steps:

Step 1. First, make sure your PC and the VTO are well connected, and follow steps below to login WEB interface.

Step 2. In Internet Explorer, input IP address of the VTO, and press Enter. System shows Figure 3- 1.

Step 3. Input Username and Password.

Step 4. Click on Login.

Note:

Default IP address of VTO is 192.168.1.110. Default username and password is admin/admin. After first login, please change your password.



Figure 3- 1

3.2 General Config


If you first use VTO, you may need to operate according to the following steps:

Step 1. In Internet Explorer, input IP address of the VTO, and press Enter.

Note:

Default IP address of VTO is 192.168.1.110. Default username and password is admin/admin. After first login, please change your password.

Step 2. In WEB interface, select System Config>Local Config, set video format as WVGA as in Figure 3- 2.




The screenshot shows the 'Local Config' tab in a web interface. It contains several configuration fields: 'Video Format' is set to 'WVGA' (dropdown), 'Device Type' is 'Villa Station' (dropdown), 'Frame Rate' is '25' (dropdown), 'Reboot Date' is 'Tuesday' (dropdown), and 'Sensitivity of fill light to open' is '60' (text input). A 'Version Info' field shows '2014-04-23 V1.0.0.0'. At the bottom are 'Default', 'Refresh', and 'OK' buttons.

Figure 3- 2

Step 3. In System Time tab, click on Sync PC to make VTO time the same with PC.

Step 4. Select System Config>Network Config, set VTO IP, Subnet Mask and Default Gateway. See Figure 3- 3.



The screenshot shows the 'Network Config' tab in a web interface. It contains four text input fields: 'IP Address' with '10.15.6.141', 'Subnet Mask' with '255.255.0.0', 'Default Gateway' with '10.15.0.1', and 'MAC Address' with '90:02:a9:b9:8f:bb'. At the bottom are 'Default', 'Refresh', and 'OK' buttons.

Figure 3- 3

Step 5. (Optional) If VTO connects to VTMS platform, System Config>LAN Config, set Area No. Section No. Building No. and etc. These parameters must match settings on VTMS Client. Please refer to Appendix 2 and 3. See Figure 3- 4.

LAN Config

Building No. 01

Building Unit No. 1

VTO No. 6901 ☐ Group Call

Figure 3- 4

Add device

SN:

Name: *

Type: * VTO =VTO ty

Manufacturer: * dahu

Position: * Community 1 Building 1

Unit 1 6901

Net Address: 0 . 0 . 0 . 0

Sub Net: 0 . 0 . 0 . 0

Gate Way: 0 . 0 . 0 . 0

Net Port: 0

Switch: =Switch=

Recieve Notice: ☒

Comments:

Type & location can't be changed after saving!

Save Cancel

Figure 3- 5

Note:

When you configure one-to-multiple scene, different VTOs shall have different VTO no. and same building no. and unit no., in order to form a proper network.

4 Web Config

This chapter introduces VTO WEB interface and its parameters, and how to configure them.

4.1 System Config

4.1.1 Local Config

4.1.1.1 Local Config

In Local Config interface, you can view VTO model, version info and etc.

The screenshot shows the 'Local Config' interface of the VTO web management system. On the left is a sidebar menu with 'System Config' expanded and 'Local Config' selected. The main panel has four tabs: 'Local Config', 'A&C Manager', 'System Time', and 'Config Manager'. The 'Local Config' tab is active, displaying several configuration parameters: 'Video Format' (WVGA), 'Frame Rate' (25), 'Sensitivity of fill light to open' (60), 'Device Type' (Villa Station), 'Reboot Date' (Tuesday), and 'Version Info' (2014-04-23 V1.0.0.0). At the bottom of the main panel are three buttons: 'Default', 'Refresh', and 'OK'.

Figure 4- 1

Parameter	Note
Video Format	Set video format that collected by the camera, including: WVGA and D1. WVGA resolution is 800×480; D1 resolution is 704×576.
Device Type	Display device type.
Frame Rate	NTSC: 30 fps, PAL: 25 fps.
Reboot Date	On the set date, device will automatically reboot.
Sensitivity of fill light to open	Set threshold of light.
Version Info	Display device version info.
Default	Only restore current Local Config page to default settings.

4.1.1.2 A&C Manager

System Config

- > Local Config
- > LAN Config
- > Indoor Manager
- > Network Config
- > Video Set
- > User Manage

Local Config | **A&C Manager** | System Time | Config Manager

Unlock Responding Interval: 15 Door Sensor Check Time: 30 ☐ Check Door Sensor Signal Before Lock

Unlock Period: 2

Default Refresh OK

Figure 4- 2

Parameter	Note
Unlock Responding Interval	The interval between current unlock and next one, unit is second.
Unlock Period	Period door remains unlocked, unit is second.
Door Sensor Check Time	When only use door sensor, check "Check Door Sensor Signal Before Lock", Set "Door Sensor Check Time" to enable it.
Check Door Sensor Signal Before Lock	When door remains unlocked over set door sensor check time, it alarms.

4.1.1.3 System Time

Here you can set date format, time format, and input system date and time. You can also click on Sync PC to synchronize system time with PC time.

4.1.2 LAN Config

Here you can register VTO to center and set how to call center. Please refer to Ch 5.1.1.

4.1.3 Indoor Manager

In Indoor Manager interface, you can add VTH (digital indoor station), view VTH info and delete VTH.

System Config

- > Local Config
- > LAN Config
- > **Indoor Manager**
- > Network Config
- > Video Set
- > User Manage

Indoor Manager


Digital Indoor Station Manager

FamilyName	FirstName	Nick Name	Room No.	IP Address	Card No. Info	Modify	Delete
test	for		9901	192.168.1.108			

Figure 4- 3

Add VTH

In Indoor Manager interface, click on Add. The system pops up a window as in Figure 4- 4.



The screenshot shows a standard Windows-style dialog box titled "Add". It features a close button (X) in the top right corner. The dialog contains five text input fields arranged vertically, each with a label to its left: "FamilyName", "FirstName", "Nick Name", "VTH Short No.", and "IP Address". The "VTH Short No." field is marked with a red asterisk (*) at its right end, signifying it is a required field. At the bottom of the dialog, there are two buttons: "OK" and "Cancel".

Figure 4- 4

Fill in VTH info as user's name, VTH short no. and IP address.

Note:

VTH short no. consists of four digits, the first two digits can be within 01~99, the last two digits can be within 01~16.

Note:

Parameters with * are mandatory.

4.1.4 Network Config

Here you can set VTO IP address, Subnet Mask and Default Gateway.

After you have modified IP address, Web page will reboot and go to the new IP address web page. See Figure 4- 5.




Figure 4- 5

4.1.5 Video Set

You can set video effect and volume in Video Set interface. See Figure 4- 6.




Figure 4- 6

Parameter	Note
Gain	Gain limit of video basic parameter.
Scene Mode	Select mode: automatic, sunny, night and etc.
Day/Night Mode	Color mode.
Back Light Mode	Back light for special environment.
Mirror	Make image displayed in mirror.

Flip	Display image in flip.
VTO Mic Volume	Set VTO MIC volume size.
VTO Beep Volume	Set VTO beep volume size.
Default	Reset video effect and volume to default.
Unlock	Unlock via web.

4.1.6 User Manage

Only when you login as admin, you can add, modify, delete and view user info in User Manage interface.

- Add User

In User Manage interface, click on Add User, system pops up Figure 4- 7. Fill in user info.





Figure 4- 7

- Modify User

In User Manage interface, click on , system pops up Modify User interface. Check Change Password, and change password and remark, see Figure 4- 8.

Index	Room No.	Event State	Channel	Begin Time
-------	----------	-------------	---------	------------

Figure 4- 10

4.3 Status Statistics

4.3.1 VTH Status

Here you can view connection status of VTH.

- Status

Offline: VTO and VTH are not connected, you cannot call, monitor, talk or etc.

Online: VTO and VTH are connected, you can call, monitor, talk and etc.

- MON

- Unmon: VTH is not monitoring.

- Onmom: VTH is monitoring.

See Figure 4- 11.

VTH	Status	MON	IP Port	Reg Time	Off Time
9901	Offline	Unmon	192.168.1.108:0	0	0

Figure 4- 11

4.4 Logout

Here you can reboot device or logout.

Click on logout to log out the system and it returns to login page.

5 Basic Function Introduction

5.1 Call Function

5.1.1 Call Manager Center

Check Register to the MGT Center, you can touch the Call button to call manager center. Now VTO can only call MGT Center, cannot call VTH. Manager center's time can be set on management platform or villa VTO's web-end. Once manager center picks up the call, you can perform a visual bidirectional talk with the manager center. You can touch the button on VTO to end call at any time.

- Step 1. According to VTO configured for the center, fill in building no, building unit no. and VTO no.
- Step 2. In LAN Config, check register to the MGT center, as in Figure 5- 1.
- Step 3. Fill in MGT center IP address and MGT port no.
- Step 4. Set call VTS time. Within this period, VTO can only call the center.
- Step 5. Check Call VTS or not.
- Step 6. Confirm all config, and click on OK. Enter Logout→ Reboot Devices, to manually reboot the device.

The screenshot displays the 'LAN Config' interface. On the left is a dark sidebar with a menu containing 'System Config' (expanded), 'Local Config', 'LAN Config' (highlighted), 'Indoor Manager', 'Network Config', 'Video Set', 'User Manage', 'Info Search', 'Status Statistics', and 'Logout'. The main area is titled 'LAN Config' and contains the following fields and controls:

- Building No.
- Building Unit No.
- VTO No. ☐ Group Call
- MGT Centre IP Address ☒ Register to the MGT Centre
- MGT Port No.
- Call VTS Time : To : ☐ Call VTS Or Not

A red warning message at the bottom states: 'Warning: The device needs reboot after modifying the config above.' Below this are three buttons: 'Default', 'Refresh', and 'OK'.

Figure 5- 1

5.1.2 Call User

Press Call button under standby status, and the VTO will call user. User may monitor VTO from VTH.

- On VTH, press Unlock button to unlock door.
- When VTH picks up, you can start talk with the VTH.
- If no one answers the call, then the call will end automatically and device returns to standby status.

5.1.3 Group Call

Group call is mainly used for one VTO. Press Call button on VTO to call multiple VTH at the same time.

VTH consists of master VTH and extension VTH. A system can only have a max of 1 master VTH and 5 extension VTHs. Please refer to VTO2000A Series Installation Guide V 1.0.0.

Set VTO

Step 1. Select System Config>Indoor Station Manager, system shows Indoor Station interface.

Step 2. In Indoor Station Manager interface, click on  to delete default VTH.

Step 3. Click on Add, input VTH Short No., IP Address (optional) to add a VTH. See Figure 5- 2.

Note:

In Indoor Station interface, you only need to add main VTH, and you do not need to add extension.




Figure 5- 2

Note:

Paramete with * are mandantory to be set.

Step 4. In LAN Config interface, check Group Call, and click on OK. See Figure 5- 3.

Step 5. After config is complete, enter Logout interface to reboot VTO.




Figure 5- 3


Set Main VTH

Step 1. On VTH screen, press System Settings>Project Settings, input password (default is 002236) to enter Project Settings interface.

Step 2. Press Product Info, input Room No., Local IP and etc as in Figure 5- 4.

Note:

Room No. must match setting in VTH Short No. In Figure 5- 4.




The screenshot shows the 'Project Settings' screen. At the top, there are icons for a monitor and a server, and a home button. The title 'Project Settings' is centered. On the right, there is a vertical menu with options: 'Product Info' (highlighted with an orange bar and a left arrow), 'Network', 'IPC Info', 'Default', and 'Back' (with a right arrow). The main area contains the following fields:

Room No.	102	Master
Local IP	172 · 5 · 1 · 105	
Subnet Mask	255 · 255 · 0 · 0	
Gateway	172 · 5 · 0 · 1	
MAC	00:01:5b:a1:33:44	
Version	Eng_P_V1.100.0000.0.R.20130428	


At the bottom center is an 'OK' button.

Figure 5- 4

Step 3. Press Network, input VTO IP Address. See Figure 5- 5.



The screenshot shows the 'Project Settings' screen with the 'Network' option selected in the right-hand menu (highlighted with an orange bar and a left arrow). The main area contains the following fields:

Main_VTO Name	Main VTO
Device Type	Unit Door Station
VTO Middle No.	10116901
VTO IP Address	172 · 5 · 1 · 31
Network Port	13801
Enable Status	ON 

At the bottom center is an 'OK' button.

Figure 5- 5

Set Extension

- Step 1. On VTH screen, press System Settings>Project Settings, input password (default is 002236) to enter Project Settings interface.
- Step 2. Press Product Info. Press Master, Master icon becomes Extension icon.
- Step 3. Set Room No. (i.e. 1101-1), input IP Address, Subnet Mask and Gateway.
- Step 4. In Master IP, input IP of the main VTH. After completion, extension will automatically sync with main VTH info configured by user. See Figure 5- 6.

The screenshot displays the 'Project Settings' interface. At the top, there are icons for a monitor and a VTH unit, and a title bar with a home icon. The main area contains several input fields: 'Room No.' with the value '102-1' and an 'Extension' button; 'Local IP' with the value '172 · 5 · 1 · 106'; 'Subnet Mask' with the value '255 · 255 · 0 · 0'; 'Gateway' with the value '172 · 5 · 0 · 1'; 'MAC' with the value '90:02:a9:80:20:e7'; 'Version' with the value 'Eng_P_V1.100.0000.0.R.20130511'; and 'Master IP' with the value '172 · 5 · 1 · 105'. An 'OK' button is located at the bottom. On the right side, there is a vertical menu with options: 'Product Info' (highlighted in orange), 'Network', 'IPC Info', 'Default', and 'Back'.

Figure 5- 6

5.2 Monitor

Both VTS and VTH are able to monitor this VTO by enabling the camera to capture local circumstance.

5.3 Unlock Function

Unlock by Center

When center is called, calling or monitoring, center can remotely unlock door. VTO will return to standby interface after call ends or countdown stops.

Unlock by VTH

When VTH is called, calling or monitoring, VTH can remotely unlock door. VTO will return

to standby interface after call ends or countdown stops.

5.4 Compensation of Light

In dark environment or at night, the VTO adopts auto photoreception technology which achieves light compensation in connecting status.

5.5 Vandal Proof

There is one channel of vandal proof which will generate alarm sound and report to the manager center once VTO is forced to leave the wall.

5.6 Restore Backup

Restore Card Info

If you encounter abnormality with card info or accidentally restore default settings, you can restore card info with this function.

Restore VTH Info

If VTH info is mistakenly changed, you can restore VTH info with this function.

Note: Every half hour, VTO automatically saves card and VTH info in the system. If you want to restore card and/or VTH info, you must restore within half hour after your last operation that change these info.

6 FAQ

1. Q: I pressed Call button, and the indicator turned on, but the VTO did not start a call?
A: Please check your operation process.
2. Q: How to end a call when I am calling?
A: Please press button on VTO and there will be sound from the device.
3. Q: The device could not boot up and there was no sound or light.
A: Please check if power supply is well plugged.
4. Q: My call did not go through.
A: It is network connection error; please check the cables of the device and its extension.
5. Q: I have other problems not included above.
A: Please contact technical staffs for assistance.

Appendix 1 Technical Specifications

Model		VTO2000A-2
System	Main Process	Embedded micro controller
	OS	Embedded Linux os
Video	Video Compression Standard	H.264
	Input/Sensor	1.3 Megapixel CMOS HD camera
	Night Vision	Support
Audio	Input	Omnidirectional Mic
	Output	Built-in speaker
	Talk	Support bidirectional talk
Operation Mode	Input	Single key input
	Door Lock Status Check	Support (optional)
Network	Ethernet	10M/100Mbps self-fit
	Network Protocol	TCP/IP
General	Power	DC 24V
	Consumption	Standby $\leq 1W$; working $\leq 7W$
	Working Temperature	- 30°C ~ +60°C
	Relative Humidity	10%~90%RH
	Dimension (L×W×H)	129.9mm×32.2mm×140mm
	Weight	0.8kg

Appendix 2 Technical Specifications

Appendix 2.1 Cable Specification

The wiring length between VTO and VTH is L_N , so reasonable specification of wiring is:

Cable Specification	$0 < L_N \leq 50\text{m}$	$50 < L_N \leq 100\text{m}$
UTP Cat5e/Cat6: 10 ohm/100m	Optional	Optional
UTP Cat5e/Cat6: 18.8 ohm/100m	Optional	Not optional

Note:

Please do not let L_N be over 100m.

Appendix 2.2 Power Extension Line Specification

The wiring length between VTO and adaptor is L_C , so reasonable specification of extension line is:

Extension Line Specification	$0 < L_C \leq 30\text{m}$	$30 < L_C \leq 100\text{m}$
20AWG	Optional	Not optional
18AWG	Optional	Optional
17AWG	Optional	Optional

Note:

Before plugging extension line to power, make sure its positive and negative end are correctly wired.

Appendix 2.3 Embedded Box


VTO Model	Embedded Box
VTO2000A-2	Case 126*115

Appendix 3 VTMS

● Check Installation Environment


This manual makes Window XP as example to introduce how to modify IP of PC in order to connect VTMS and monitoirng system.

Step 1. Select Start>Control Panel>Network Connection>Local Area Connection, right click on Local Area Connection icem, select Properties, see Appendix 3- 1.



Appendix 3- 1

Step 2. View and modify IP address, make it in the same segment with VTO. See Appendix 3- 2.



Appendix 3- 2

Step 3. After complete modification, select Start>Run, input “cmd”, click on OK. Enter command interface, input “ping” + IP of the VTO. If it obtains communication data, then VTO and the PC are connected. See Appendix 3- 3.

```

C:\WINDOWS\system32\cmd.exe
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

C:\Documents and Settings\10881>ping 10.22.5.189

```

Appendix 3- 3

- **Enable VTMS**

The following mainly introduces how to config VTMS for you to login VTO and use VTMS.

Step 1. Install VTMS on PC.



Step 2. Double click on `zw_guard...`, click on Start service, and VTMS will boot up.

Image	Create	CPU(%)	memory(K)	Threads	Process ID	Parent ID	Priority(0-31)
mysqld_zwan.exe	11/18/2013 09:00:53	0	13484	30	444	548	8
java_zwan.exe	11/18/2013 09:01:01	0	129692	169	3016	816	8
VTS_PMU.exe	11/18/2013 09:01:21	0	9980	19	3660	816	8

Appendix 3- 4

Appendix 4 VTMS Client

This following mainly introduces how to config VTMS Client.


Appendix 4.1 Config Network Address

Step 1. Install VTMS Client on PC.



Step 2. Double click on VTMS.exe, in pop-up box input username, password, IP address, port and etc. Click on Login. See Appendix 4- 1.

Note: Default username and password is admin and 123, respectively. After first successful login, please change password.

A screenshot of the VTMS Client login window. The window has a blue header with the text 'Vision Telephone Manage System'. Below the header, there are input fields for 'name' (containing 'admin'), 'pwd' (containing '***'), 'ip' (containing '172.5.1.107'), and 'port' (containing '8787'). There are also checkboxes for 'auto login' (unchecked) and 'save pwd' (checked). At the bottom, there are two buttons: 'Login' and 'Cancel'.


Appendix 4- 1

Step 3. In main interface, click on Device MGR. See Appendix 4- 2.



Appendix 4- 2

- Step 4. Double click on VTS parameter column, system pops up Edit device box, input PC's IP address. See Appendix 4- 3.



SN: 330103000000800053

Name: * VTS

Type: * VTS

Manufacturer: * Dahu

Net Address: 172 . 5 . 1 . 107


Net Port: 12801

Comments:

Changed Save Cancel

Appendix 4- 3

- Step 5. Click on Save. Input project password (default project password is 123).
- Step 6. Re-login VTMS, you can see VTMS is successfully configured as in Appendix 4- 4.




Appendix 4- 4

Appendix 4.2 Create Organization

First you must build up environment and set VTMS server, please refer to Appendix 3. This chapter takes example of a residence with 10 buildings and 2 units.


● Create Residence Organization

Step 1. In VTMS main interface, select Organization, click on Batch Add. System pops up Batch Add box, see Appendix 4- 5.



Appendix 4- 5

Step 2. Click on OK to save. The created organization is as in Appendix 4- 6.



Appendix 4- 6

● Add VTO

Step 1. In VTMS main interface, select Device MGR, click on Add, system pops up Batch Add box.

Step 2. Fill in info according to your actual condition, and click on Save. See Appendix 4- 7.

Add device

SN:

Name: *

Type: * **VTO**

Manufacturer: * **dahu**

Position: * **Community 1** **Building 1**

Unit 1

Net Address: . . .

Sub Net: . . .

Gate Way: . . .

Net Port:

Switch: **=Switch=**

Recieve Notice: ☒

Comments:

Type & location can't be changed after saving!

Appendix 4- 7

- **Add VTH**

- Step 1. In VTMS main interface, select Device MGR, click on Batch Add, system pops up Batch Add box.
- Step 2. Fill in info according to your actual condition, and click on Save. See Appendix 4- 8.

The image shows a 'Batch Add' dialog box with a blue header and a close button (X) in the top right corner. The dialog contains several configuration fields, each with a red asterisk indicating it is required:

- Device Type:** A dropdown menu with 'VTH' selected.
- VTH type:** A dropdown menu with 'Digital' selected.
- Manufacturer:** A dropdown menu with 'dahu' selected.
- Community:** A dropdown menu with 'Community 1' selected.
- Building:** A dropdown menu with 'Building 1' selected.
- Unit:** A dropdown menu with 'Unit 1' selected.
- Floors per unit:** A numeric input field with '10' entered.
- House per floor:** A numeric input field with '2' entered.

At the bottom right of the dialog, there are two buttons: a green 'Add' button with a plus icon and a red 'Cancel' button with an X icon.

Appendix 4- 8

Note:

- This manual is for reference only. Slight difference may be found in user interface.
- All the designs and software here are subject to change without prior written notice.
- All trademarks and registered trademarks are the properties of their respective owners.
- If there is any uncertainty or controversy, please refer to the final explanation of us.
- Please visit our website or contact your local service engineer for more information.
-