

Тест на eSATA Storage модел: ESS1508C

Налични позиции за HDD: 8 до 48TB;

Възможност за комуникация по eSATA/USB3.0.

Поддръжка на модели: HCVR5804/5808/5816S-V2, HCVR5404/5408/5416L-V2, NVR5416/5432/5464(-16P)-4KS2, NVR5816/5832/5864(-16P)-4KS2, NVR5416/5432/5464-4KS2, NVR5416/5432/5464-16P-4KS2, NVR5816/5832/5864-4KS2, NVR4408/4416/4432, NVR4408/4416/4432-8P, NVR4416/4432-16P, NVR4808/4816/4832, NVR4816/4832-16P.

Няма собствен мениджмънт.

Менажиране на 8-те диска през мениджмънта на главното устройство:

The screenshot shows the 'HDD MANAGE' section of a web interface. At the top, there are tabs: PREVIEW, PLAYBACK, SMART PLAY, ALARM, SETUP, INFO, and LOGOUT. Below the tabs is the 'HDD MANAGE' header. The main area contains a table with the following columns: Device Name, Physical Position, HDD Operation, Status, and Free Space/Total Space.

Device Name	Physical Position	HDD Operation	Status	Free Space/Total Space
sdc	host_8	Read-Write	Normal	5.45TB/5.45TB
sda	eSATA-1	Read-Write	Normal	3.63TB/3.63TB
sdb	eSATA-2	Read-Write	Normal	3.63TB/3.63TB

Below the table are buttons for OK, Refresh, and Format. In the bottom right corner, it says 'HDD.No. : 3'.

Възможност за създаване на до 24 групи (няма възможност от един HDD да се правят няколко групи, 1 диск за 1 група):

The screenshot shows the 'HDD' configuration section of a web interface. On the left is a sidebar menu with options: IMAGE, NETWORK, EVENT, STORAGE, SCHEDULE, HDD MANAGE, RECORD, ADVANCED (highlighted), RAID, ISCSI, SYSTEM, and CLUSTER SERVICE. The main area has tabs: HDD, Main Stream, Sub Stream, and Snapshot. The 'HDD' tab is active, showing a table with columns: Name and HDD Group.

Name	HDD Group
sda	1
sdb	2
sdc	3

Below the table are buttons for OK and Refresh. A red circle highlights the 'HDD Group' column.

Възможност за индивидуално присъединяване на всички канал от устройството към дадена група дефинирана преди това. Възможност за различна група за 3-те отделни категории за запис: Main, sub stream и snapshot.

The screenshot shows the 'Channel' configuration section of a web interface. On the left is a sidebar menu with options: IMAGE, NETWORK, EVENT, STORAGE, SCHEDULE, HDD MANAGE, RECORD, ADVANCED (highlighted), RAID, ISCSI, SYSTEM, and CLUSTER SERVICE. The main area has tabs: HDD, Main Stream, Sub Stream, and Snapshot. The 'Main Stream' tab is active, showing a table with columns: Channel, HDD Group, Channel, HDD Group, and Channel.

Channel	HDD Group	Channel	HDD Group	Channel
Channel 1	1	Channel 2	1	Channel 3
Channel 5	2	Channel 6	2	Channel 7
Channel 9	3	Channel 10	1	Channel 11
Channel 13	1	Channel 14	1	Channel 15
Channel 17	1	Channel 18	1	Channel 19
Channel 21	1	Channel 22	1	Channel 23
Channel 25	2	Channel 26	1	Channel 27
Channel 29	1	Channel 30	1	Channel 31

Below the table are buttons for OK, Refresh, and Copy.

Възможност за задаване типа на твърдия диск (диск за запис на данни или диск за backup) при форматирането му.



Недостатък е невъзможността за използване на дисковете от сториджа за създаването на RAID масив (ако главното устройство поддържа възможността за конфигуриране на RAID). RAID-а се формира само от дисковете в главното устройство (NVR/DVR).

