DSS7016/DSS4004 Upgrade Manual

1. Login manager web.




2、Select System->Upload, and click button to download the Configtool.



3. Choose at downloaded folder and unzip. Click to open

DSSConfig folder and unzip the file upgradeTool.zip , then select

ConfigTool.exe file to open.




4、Click Login and pop up Login interface, input IP address, Username, Password and Port of DSS7016 or DSS4004, then Login.

Note: User name is "admin" and Password are "123456" in Default, when the password of Config System is modified, the upgrade system's password will be modified synchronously. the port is 3800.

This rule is only valid for such versions listed in the following. Otherwise, the password is "admin" but not "123456" and it will not be modified when the config system's password is modified.

- ✓ DSS-B: the version after V3.11.002.R.20150702(include)
- ✓ DSS-M: the version after V3.11.003.R.20151202(include)
- ✓ DSS-T, DSS-H: all version



4. Download and copy the upgrading file to PC. Click "open" button to select the upgrading file, and click "Upgrade" button.

About 5 minute later, system will prompt Upgrade Finished and Reboot, click OK to finish the upgrade.

Note: Make sure the upgrading file which is copied to PC is complete, if not or select the file from u DISK directly, system will prompt file error.

