

Premier SmartKey User Guide

1. To turn on press  and hold for 4 secs.
 2. To Arm press .
 3. To Part Arm press .
 4. To Disarm press .
 5. To activate Panic Alarm press  and  hold together for 4 secs.
 6. To turn off press  and hold for 4 secs.
- Note: The SmartKey will power off after 20 seconds of no activity.

ALARM STATUS LED's

- Green LED on = Disarmed
- Orange LED flashing = Part Arming
- Orange LED on = Part Armed
- Red LED flashing = Arming
- Red LED on = Armed
- All 3 LED's flashing together = Alarm
- All 3 LED's cycling = Panic Alarm

SMARTKEY STATUS LED

- Green LED on = Connection successful
- Red LED on = Connection Unsuccessful

