

## Close telnet

——For all DVR / HCVR / NVR

1. Run Upgrade.exe



2. Input IP address, port, username & password of the device



3. Click Upgrade and wait, it will show Upgrade successful