

## **Appendix 1**

### **Installation instruction for SuperCam (Windows Phone7)**

Step1:Enter into Marketplace function of WP7;

Step2:Type 'SuperCam' to search. Click the software when you get it;


Step3:Click 'INSTALL' to download and install;

Step4:After finished, you will find the software on your phone;

## Appendix 2

### User manual for SuperCam (Windows Phone7)

#### 1. Login




The login form is titled "Login" in a large blue font. It contains three input fields: "Server:" with a dropdown arrow, "User:" with a text box, and "Password:" with a text box. Below these fields is a blue "Login" button. At the bottom, there is a checkbox labeled "Remember me".

Enter server's IP address (or domain name), user's ID and password.


Click "Remember server" to save the setting; click ▼ button can quick input saved server address, user name and password.




2. Live view



Icon	Functional description
	Enter PTZ control
	Snap
	Channel status/switch

3. Image



Icon	Functional description
	Previous
	Next
	Delete

4. Server list



Icon	Functional description
	Add a server list
	Modify a server list
	Delete a server list

## 5. Setting

### Setting

Motion alarm	<input checked="" type="checkbox"/>
Sensor alarm	<input type="checkbox"/>
Video loss alarm	<input checked="" type="checkbox"/>
Sound	<input type="checkbox"/>
Vibration	<input checked="" type="checkbox"/>

## 6. Information

### Information

#### About server

Server ID : 1

Server name : EDVR

Server software version : 3.1.81.P-1.0.4.2-00

Server build date : 20110521

#### About client

Client software version : 1.0.0

Client build date : 20110913