

[If no previous version was installed move to page 2](#)

[- Page 1 -](#)

Removing previous Version of CP210x Silabs

1. Enter to ADD/Remove program and remove

- "Silicon Laboratories CP210x USB"
- "Silicon Laboratories CP210x VCP"

Note: if you see more components regarding to "Silicon Laboratories" remove them also.



Once you remove all the previous CP210x components, it is possible that you will be asked to preformed restart – **Do not restart yet!!!!**

Remove the "Silabs" directory from c:\,
And from c:\Program Files\Silabs

When you removed the directory "Silabs" **Restart** your computer and move to the installation process below.

CP210x_VCP_Win2K_XP_S2K3

Before you connect the USB device:

Extract the file to your desktop.

Run the extract file into the path that the software will give to you automatically:
(C:\SiLabs\MCU\CP210x\Windows_2K_XP_S2K3_Vista)

- If you will be ask to restart you computer – Please do it!

After the installation is complete, you can connect the USB device. The computer probably will find the installation by oneself, but if not – send him to:

C:\Program Files\Silabs\MCU\CP210x

https://www.mysilabs.com/public/documents/software_doc/drivers/Microcontrollers/Interface/en/CP210x_VCP_Win2K_XP_S2K3.exe